


User manual

TP5008

a multifunctional
PC measuring instrument

2 analog inputs, 8 bits
1 analog output, 8 bits



TiePie engineering

ATTENTION!

Measuring directly on the **LINE VOLTAGE** can be very dangerous. The **OUTSIDE** of the **BNC CONNECTORS** at the **TP5008** are connected with the **GROUND** of the computer.

Use a good isolation transformer or a differential probe when measuring at the **LINE VOLTAGE** or at **GROUND-ED POWER SUPPLIES!**

In case this has not been considered and the **GROUND** of the **TP5008** is connected to a positive voltage, a short-circuit current will be flowing. Because of this short-circuit current both the **TP5008** and the computer can be damaged.

Despite the care taken for the compilation of this user manual, **TiePie engineering** can not be held responsible for any damages resulting from errors that may appear in this book.

All rights reserved. No part of this book may be reproduced, stored in a database or retrieval system, or published, in any form or in any way, electronically, mechanically, by print, photoprint, microfilm or any other means without prior written permission from **TiePie engineering**.


User manual

Afbeelding niet beschikbaar

TP5008

a multifunctional
PC measuring instrument

2 analog inputs, 8 bits
1 analog output, 8 bits



TiePie engineering

Contents

Safety	5
Declaration of conformity	7
Introduction	9
Sampling	9
- Aliasing	10
Digitizing	12
The oscilloscope	12
The spectrum analyzer	13
The voltmeter	14
The transient recorder	15
Hardware installation	17
Software	19
Structure of the program	20
Starting the program	20
Controlling the program	22
- Controlling by mouse	22
- Controlling the main menu	22
- Controlling popup menus	23
Help screens	23
Program settings	24
- Saving instrument settings	24
- Loading instruments settings	24
- Setting the file type for measurement data	24
- Setting the location of files	25
- Setting the default TP5008 address	25
- Setting the printer port	25
- Setting the printer type	25
- Default text on the printer output	25
- Setting the screen colors	26
Storing measurement data on disk	26

Loading saved measurement data	26
Printing measured data	27
Choosing an instrument	28
Terminating the program	28
Oscilloscope (device: LIVE)	29
Aliasing	29
Displaying channels	30
Setting up a channel	31
- Setting the sensitivity of a channel	31
- Setting the vertical position of a channel	31
- Enlarging or reducing the vertical axis	33
- Changing the units of the vertical axis	33
Setting up the time axis	35
- Setting the timebase	35
- Magnification of the horizontal axis	35
Triggering	36
- Selecting the trigger source	37
- Setting the trigger hysteresis	37
- Setting the trigger slope	37
- Adjusting the trigger level	38
- Setting the trigger time-out	39
- Stopping the display	39
Magnifying a part of the screen	40
Storage oscilloscope (device: HOLD)	41
Differences with the oscilloscope	41
Measuring with the cross hair	41
Spectrum analyzer (device: SPECTRUM)	43
Description of FFT	43
- Aliasing	44
- Windowing	44
Similarities with the oscilloscope	49
Displaying channels	49
Setting up a channel	49
- Setting the sensitivity	49
- Adapting the vertical axis	50
Setting up the frequency axis	50
- Magnifying the frequency axis	50

Selecting the window	51
Averaging of spectra	51
Starting a spectrum measurement	52
Measuring a harmonic distortion	52
Calculate the spectrum from the HOLD signal	52
Voltmeter (device: VOLT)	53
Setting up a channel	53
- Setting the input range	53
- Changing the units of measure	54
- Changing the units per volt	54
- Relative measurements	54
- Comparison measurements	55
- Setting the impedance	55
- Setting the gate time	55
- Processing the measured data	55
- Displaying the measured value	57
Setting the frequency range	58
Zeroing the voltmeter	59
Perform measurements	60
Storing measurement values on disk or paper	60
- Setting the time between two measurements	60
- Start an acquisition	61
Changing the display characters	61
Transient recorder (device: TRANS)	63
Setting the measuring type	63
- Setting the frequency range	64
Setting the sampling time	64
Setting the number of samples	65
Clear the screen	65
Start a measurement	65
Go to a specific sample	66
Programmable signal generator	67
Installing the software	67
Setting up the signal	67
- Waveform	67
- Amplitude	67
- Number of periods	68

- Frequency	68
- Symetry	68
- Envelope	68
- Envelope amplitude	68
- Envelope periods	68
- DC level	69
- Burst ratio	69
Generating the signal	69
Ending the generator program	69
Hardware	71
Connections	72
Hardware diagram	73
Description of the hardware	74
- Setting the input sensitivity	75
Programming the TP5008	77
Specifications	79
Hardware	79
- A/D convertor	79
- D/A convertor	79
- General	80
Software	80
- Spectrum analyzer	80
- Oscilloscope	81
- True RMS voltmeter	82
- Transient recorder	82



Safety



Before you start working with the TP5008, first read these safety rules.

- Avoid working **alone**.
- Check the probes / test leads for damages. Do **NOT** use them if they are damaged.
- Take care when measuring at voltages higher than 25V AC or 60 VDC.
- Measuring directly on the LINE VOLTAGE can be very dangerous. The OUTSIDE of the BNC CONNECTORS at the TP5008 are connected with the GROUND of the computer. Use a good isolation transformer or a differential probe when measuring at the LINE VOLTAGE or at GROUNDED POWER SUPPLIES!

In case this has not been considered and the GROUND of the TP5008 is connected to a positive voltage, a short-circuit current will be flowing. Because of this short-circuit current both the TP5008 and the computer can be damaged.

Declaration of confirmity

 <p>TiePie engineering Battenserreed 2 9023 AR Jorwerd Nederland</p> <p>EG-verklaring van overeenstemming</p> <p>Wij verklaren geheel onder eigen verantwoordelijkheid, dat het produkt</p> <p>TP5008</p> <p>waarop deze verklaring betrekking heeft, in overeenstemming is met de geharmoniseerde Europese normen</p> <p>EN 55011, EN 55022, EN 50081-1 en EN 50082-1</p> <p>Volgens de bepalingen van de EMC-richtlijn 89/336/EEG, gewijzigd door de richtlijn 92/31/EEG en 93/68/EEG</p> <p>Jorwerd, 2-1-1996 ir. A.P.W.M. Poelsma</p>	 <p>TiePie engineering Battenserreed 2 9023 AR Jorwerd The Netherlands</p> <p>EC declaration of Conformity</p> <p>We declare, on our own responsibility, that the product</p> <p>TP5008</p> <p>for which this declaration is valid, is in compliance with</p> <p>EN 55011, EN 55022, EN 50081-1 and EN 50082-1</p> <p>according to the conditions of the EMC standard 89/336/EEG, and the amendments 92/31/EEC and 93/68/EEC</p> <p>Jorwerd, 2-1-1996 ir. A.P.W.M. Poelsma</p>
---	--

 <p>TiePie engineering Battenserreed 2 9023 AR Jorwerd The Netherlands</p> <p>EG - Konformitätserklärung</p> <p>Wir erklären, in Eigenverantwortlichkeit, hiermit, daß das Produkt</p> <p>TP5008</p> <p>für das diese Erklärung gültig ist, mit</p> <p>EN 55011, EN 55022, EN 50081-1 und EN 50082-1,</p> <p>gemäß den Anforderungen des EMC-standards 89/336/EEG, und den Zusatzbestimmungen 92/31/EEC und 93/68/EEC übereinstimmt.</p> <p>Jorwerd, 2-1-1996 ir. A.P.W.M. Poelsma</p>	 <p>TiePie engineering Battenserreed 2 9023 AR Jorwerd The Netherlands</p> <p>Déclaration de conformité C.E.</p> <p>Nous déclarons, sous notre responsabilité, que le produit</p> <p>TP5008</p> <p>pour lequel cette déclaration est valide, est conforme aux:</p> <p>EN 55011, EN 55022, EN 50081-1 et EN 50082-1</p> <p>selon les conditions du standard CEM N° 89/336/EEC, et les amendements 92/31/EEC et 93/68/EEC</p> <p>Jorwerd, 2-1-1996 ir. A.P.W.M. Poelsma</p>
--	---



TiePie engineering
Battenserreed 2
9023 AR Jorwerd
The Netherlands

Dichiarazione di Conformita' CE

Dichiariamo sotto la nostra esclusiva responsabilità che il prodotto:

TP5008

per il quale vale la presente dichiarazione, è conforme alle norme

EN 55011, EN 55022, EN 50081-1 e EN 50082-1

conforme alle condizioni della normativa EMC 89/336/EEC, e successive modifiche 92/31/EEC e 93/68/EEC.

Jorwerd, 2-1-1996

ir. A.P.W.M. Poelsma



TiePie engineering
Battenserreed 2
9023 AR Jorwerd
The Netherlands

EC-declaración de conformidad

Nosotros declaramos, bajo nuestra propia responsabilidad, que el producto

TP5008

para el cual esta declaración es válida, está en relación con

EN 55011, EN 55022, EN 50081-1 y EN 50082-1

Según las condiciones del EMC estándar 89/336/EEC, y los movimientos 92/31/EEC y 93/68/EEC

Jorwerd, 2-1-1996

ir. A.P.W.M. Poelsma



TiePie engineering
Battenserreed 2
9023 AR Jorwerd
The Netherlands

EF-Overensstemmelseserklæring

Undertegnede erklærer herved, at følgende apparat overholder beskyttelseskravene i Rådets direktiv 89/336/EØF om elektromagnetisk kompatibilitet (EMC).

Identification af apparat:

Kategori: Måleinstrument

Model/type: **TP5008**

Standarder der er anvendt som grundlag for erklæring, eller henvisning til den prøvningsrapport, der er udstedt af et betydningsfuldt laboratorium:

EN 55011, EN 55022, EN 50081-1 og EN 50082-1

CE-mærket angiver kun overensstemmelse med EMC-direktiv 89/336/EØF

Jorwerd, 2-1-1996

ir. A.P.W.M. Poelsma



TiePie engineering
Battenserreed 2
9023 AR Jorwerd
The Netherlands

EC Hyväksyntäilmoitus

Velvollisuutenamme on ilmoittaa, että tuotteemme

TP5008

jota tämä selvitys koskee, on hyväksytty

EN 55011, EN 55022, EN 50081-1 ja EN 50082-1

EMC standardien 89/336/EEG, ja lisästandardien 92/31/EEC ja 93/68/EEC mukaisesti

Jorwerd, 2-1-1996

ir. A.P.W.M. Poelsma

Chapter 1

Introduction



Note before using the TP5008, first read the chapter about Safety


Many technicians investigate electrical signals. Though the measurement may not be electrical, the physical variable is often converted to an electrical signal, with a special transducer. Common transducers are accelerometers, pressure probes, current clamps and temperature probes. The advantages of converting the physical parameters to electrical signals are large, since several instruments for examining electrical signals are available.

The TP5008 is a two channel, 8 bits, 200ksamples/sec measuring instrument. With the accompanying software the TP5008 can be used as an oscilloscope, a storage oscilloscope, a spectrum analyzer, a true RMS voltmeter or a transient recorder. All instruments measure by sampling the input signals, digitizing the values, process them, save them and display them.


The TP5008 also has an analog output, driven by a 8 bits, 1000ksamples/sec digital to analog convertor.

Sampling

When sampling the input signal, samples are taken at certain moments. The frequency at which the samples are taken is called the sampling frequency. By taking a (large) number of samples, the input signal can be reconstructed.




In the latter illustration a sine wave signal is sampled with 50 samples. By connecting the adjacent samples, the original signal can be reconstructed. See also the next illustration.



The more samples are taken, the better the signal can be reconstructed. The sampling frequency must be higher than 2 times the highest frequency in the input signal. This is called the Nyquist frequency. Theoretically it is possible to reconstruct the input signal with more than 2 samples. In practice, 10 to 20 samples are necessary to be able to examine the signal thoroughly.

Aliasing


If the sampling frequency is lower than 2 times the frequency of the input signal, 'aliasing' will occur. The following illustration shows how aliasing occurs.



The input signal is a triangular signal with a frequency of 1.25 kHz (upper most in the illustration). The signal is sampled at a frequency of 1 kHz. The dotted signal is the result of the reconstruction. From that triangular signal the periodical time is 4 ms, which corresponds with an apparent frequency (alias) of 250 Hz ($1.25 \text{ kHz} - 1 \text{ kHz}$).

To avoid aliasing, the sample frequency must be higher than 2 times the maximum frequency of the input signal.

Aliasing is not always visible on an oscilloscope. In the latter illustration, it gives a 'good looking' picture. It is not apparent that aliasing occurs. The next illustration gives an example of visible aliasing.



This time it is a sine wave signal with a frequency of 25.7 kHz, which is sampled at a frequency of 5 kHz. The minimal sampling frequency should

have been 51.4 kHz. For proper analysis, the sampling frequency should have been 500 khz.

Digitizing

After taking a sample of the input signal, it is digitised. This is done with an Analog to Digital Converter, ADC. The ADC converts the size of the signal to a digital number. This is called quantifying.

The first condition for accurate measurement is to have as many as possible quantifying steps. This can be realised by using an ADC with a resolution as high as possible.

The resolution of ADC's is often given in bits. The number of bits determines the number of quantifying steps according the formula:

$$\text{number of quantifying steps} = 2^{\text{number of bits}}$$

A 2 bits ADC has 4 quantifying steps. With an input range of 10 Volt, this ADC can divide the input range in 4 parts of each 2.5 Volt.

By increasing the number of bits, the resolution increases, the number of quantifying steps increases and the sub-divisions get smaller.

The oscilloscope

The oscilloscope is an instrument with which electrical voltages varying in time can be displayed. With the oscilloscope time dependent electrical signals can be examined easily. Except for the time domain, functions and dependencies of quantities can also be displayed and examined in the X-Y mode.

The TP5008 oscilloscope has two separated inputs (channels), for which the sensitivity of each channel can be set.

The TP5008 is equipped with two types of oscilloscopes, LIVE and HOLD. The oscilloscope LIVE measures 480 samples, 1 page. The

oscilloscope HOLD measures 4800 samples, 10 pages.

The sensitivity range for the channels goes from 125 mV/div to 5 V/div. The timebase goes from 0.2 msec/div to 2 sec/div.

The display of the oscilloscope is built of 480 x 360 (wxh) pixels, which corresponds with 12x8 (wxh) divisions. Left and right of the display the units of the 2 channels are displayed. Under the display, the time axis is displayed.

The spectrum analyzer

The common way to examine electrical signals is in the time domain, using an oscilloscope. The time domain is used to determine amplitude, time and phase information, which is necessary to describe the behaviour of an electrical system.

Not all electrical systems can be characterised in the time domain. Circuits like filters, amplifiers, oscillators, mixers, modulators and detectors can be characterised best by their frequency behaviour. That frequency behaviour is best obtained by observing the electrical signals in the frequency domain. To display the frequency domain, an instrument is needed that can distinguish different frequencies from each other and measure the signal size at the different frequencies. An instrument that can display the frequency domain is the spectrum analyzer. It graphically displays voltage as a function of frequency.

In the time domain all frequency components of a signal are seen summed together. In the frequency domain, complex signals (signals composed of more than one frequency) are separated in their frequency components, where the voltage of each frequency component is displayed.

The frequency domain contains information which is not available in the time domain. Therefore the spectrum analyzer has certain advantages compared with an oscilloscope.

- With a spectrum analyzer small harmonic distortions on a signal can be displayed better than on an oscilloscope. A sine wave may

look good in the time domain, however in the frequency domain the harmonic distortion is visible.

- A noise signal may look fully random in the time domain, in the frequency domain it can appear that one frequency is dominantly present.
- In the frequency domain it is very simple to determine carrier frequency, modulation frequency, modulation level and modulation distortion from a modulated signal (AM or FM).

The TP5008 is equipped with a two channel spectrum analyzer. The two channels can be set independently. The spectrum analyzer takes 1024 samples, of which a spectrum of 512 spectral components is calculated by means of FFT.

The sensitivity of the channels can be set from 125 mV/div to 5 V/div. The frequency range of the spectrum analyzer goes from 0.025 Hz to 48 kHz.

The display of the spectrum analyzer is built of 480 x 360 (wxh) pixels, which corresponds with 12x8 (wxh) divisions. Left and right of the display the units of the 2 channels are displayed. Under the display, the frequency axis is displayed.

The voltmeter

If from the input signals only the size is important and not time information or frequency components, the voltmeter is a suitable instrument to measure with. The two channel voltmeter measures the size of the input signal and displays the values using a large 7 segment display. The two independent channels each have their own display.

The voltmeter can measure the input signal in several ways:

TRUE RMS	the true RMS value is measured
PEAK PEAK	the peak peak value is measured
MEAN	the mean value is measured
MAX	the maximum value is measured
MIN	the minimum value is measured

dBm	the value is given in decibel
POWER	the power of the input signal is determined
CREST	the crest factor is calculated
FREQ.	the frequency of the input signal is measured

The input of the voltmeter is autoranging or manually settable between 500 mV full scale and 20 V full scale.

Besides this, the voltmeter has the possibility to measure at certain times and send the data to a printer or write it on disk.

The transient recorder

For measuring slowly changing signals (e.g. the temperature change in a room) the transient recorder is the most suitable instrument.

The two channel transient recorder measures the input signals at adjustable times. The time between two measurements is adjustable from 0.01 second to 300 seconds. The number of samples is also adjustable from 1 to 30000. The maximum measuring time is 300 sec x 30000 samples = 9000000 seconds (104.16 days).

The sensitivity of the two channels is adjustable between 125 mV/div and 5 V/div.

The display of the transient recorder is built of 480 x 360 (wxh) pixels, which corresponds with 12x8 (wxh) divisions. Left and right of the display the units of the 2 channels are displayed. Under the display, the time axis is displayed. In addition, the value, time and date of the samples are given.

The transient recorder measures in one of the following ways:

MOMENTAL	the momentary value of the input signal is measured
TRUE RMS	the true RMS value of the input signal is measured
MEAN	the mean value of the input signal is measured
MAX	the maximum value of the input signal is measured
MIN	the minimum value of the input signal is measured


Chapter 2

Hardware installation

The TP5008 is an 8 bits interface card, which can be placed in any free 8 or 16 bits ISA slot of an IBM compatible PC, XT or AT. The card does not use DMA or interrupts, so installation is very simple.

The only thing that has to be set is the I/O base address for the TP5008. The card can be set to any address between \$000 and \$3FC, in steps of 4 addresses. To do that, the address lines A2..A9 of the PC are needed. The address lines A0 and A1 are used to address the 4 internal addresses of the TP5008. Setting the TP5008 I/O base address is done by the dipswitch on the interface card.


The factory default setting is address \$308, what corresponds to a dipswitch setting like in the following figure.



Calculation of the I/O base address:

sw8	sw7		sw6	sw5	sw4	sw3		sw2	sw1		
A9	A8		A7	A6	A5	A4		A3	A2	A1	A0
1	1		0	0	0	0		1	0	x	x
	\$3				\$0				\$8		

If the address \$308 is already in use by another device, you can set the TP5008 to another I/O base address. Now follows an example for address \$288.



Calculation of the address \$288:

sw8	sw7	sw6	sw5	sw4	sw3	sw2	sw1		
A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
1	0	1	0	0	0	1	0	x	x
	\$2		\$8				\$8		



Note When the I/O base address of the TP5008 is changed, the software has to be altered as well. See: Setting the TP5008 I/O address.

Chapter 3

Software

Installation of the software

The software of the TP5008 is shipped on two diskettes, one with the measurement software and one with the programmable signal generator.

First you have to make a backup of the original diskettes. Refer to your DOS manual for making a backup of a diskette. When you have made the backup, store the original diskettes in a safe place and use the backup.

The measurement software is shipped ready to use, without installation program. You can run the software direct from the diskette or from a hard disk.



Hint A hard disk is much faster than a diskette and has usually more free space available to store data.

To install the software on a hard disk, first make a directory for the software. Then copy all files from the diskette 1 to the directory. The files are:

TP5008.EXE	the program
TP5_ENG.HLP	the English help file
TP5_ENG.INF	information for the help file
TP5008.FNT	font file for printing output
TP5008.DEF	file with program settings

An example, where the diskette is in drive A: and the software has to be installed in a directory called TP5008 on the C: drive.

```
C:  
MD TP5008  
CD TP5008  
COPY A:*.*
```

The software is now installed on the harddisk. After starting the program, the DEFAULT TP5008 ADDRESS has to be set. This is the IO address the TP5008 is set to. Also the DEFAULT DIRECTORIES can be set. These indicate where the program has to store and look for help files, instrument setting files and measurement data files. You can set the DEFAULT TP5008 ADDRESS and the DEFAULT DIRECTORIES with the menu **SETTINGS**, in the lower right corner of the screen.

Structure of the program

The program contains five integrated measuring instruments:

- 1 An oscilloscope, device: live.
- 2 A storage oscilloscope, device: hold.
- 3 A spectrum analyzer, device: spectrum.
- 4 A true RMS voltmeter, device: volt.
- 5 A transient recorder, device: trans.

Only one measuring instrument can be active at the same time.

From each measuring instrument another measuring instrument can be activated. Standard features of the above five measuring instruments are options to make print outs and to leave the program to return to DOS.

Starting the program

The program can easily be started according to the below-mentioned procedure:

```
TP5008 par1 par2
```

If no parameters are given, the device LIVE is selected, with the default settings.

The parameters par1 and par2 have the following meaning:

par1 Indicates the device that will be activated after starting the program. Valid values are:

- LIVE : Measuring instrument oscilloscope.
- HOLD : Measuring instrument storage oscilloscope.
- SPECTRUM : Measuring instrument spectrum analyzer.
- VOLT : Measuring instrument true RMS voltmeter.
- TRANS : Measuring instrument transient recorder.

par2 Indicates the filename of the instrument setting (see for writing or reading instrument settings: SETTINGS menu).

Example:

```
TP5008 trans b:TP5008.set
```

means the measuring instrument transient recorder is activated with the file settings b:TP5008.set. Incorrect instrument or filenames will be ignored.

The parameters par1 and par2 may be exchanged sequentially, but have to be separated by a space.



Note The TP5008 software is designed to run under DOS and not under WINDOWS. Running the software under Windows will give incorrect results.

The timebase of the TP5008 is generated by the computer. If the software is running under Windows, the software can (and will) be interrupted by Windows and other running tasks. This results in 'jumps' in the signal on the screen, since some information of the signal is missed during the interrupt.

To avoid these problems, run the software under DOS. Running from a DOS prompt within Windows will NOT solve the problems because Windows is still active. Quit Windows by pressing <Alt-F4>.

Windows 95 users: Shut down Windows 95 and restart the computer in MS-DOS mode.

Controlling the program

After starting the program, first an intro screen with program information is displayed. This screen indicates what kind of display adapter the program has detected and whether a *Microsoft*® compatible mouse is available.

After the intro screen has disappeared, the normal working screen appears. This screen is divided in two parts: a part for displaying the measurement data and a part for the main menu, for controlling the program. The program can be controlled by the keyboard as well as by a mouse.

Controlling by mouse

When using the mouse, the left mouse button is used for <Enter> and the right mouse button is used for <Esc>.

Controlling the main menu

Each instrument has its own main menu, in the lower part of the screen. The menu is built of three rows of 6 columns.

One of the buttons of the menu is always displayed inverted. That is the cursor, indicating the selected choice. For controlling the main menu, the following keys are available:



places the cursor one row up



places the cursor one row down



places the cursor one column to the left



places the cursor one column to the right



activates the selected choice

















displays a list of instruments

Depending on the choice, after activating, a popup menu appears or the text in the menu changes, as well as the instrument setting.

Controlling popup menus

Various settings in the software are made by means of popup menus. For controlling the popup menus the following keys are valid:

	Move the cursor up	
	Move the cursor down	
	Move the cursor to the top of the menu	
	Move the cursor to the bottom of the menu	
		Move the popup menu to the right
		Move the popup menu to the left
		Move the popup menu up
		Move the popup menu down
	Accept the selected choice	
	Leave the popup menu without changes	
Space	Leave the popup menu without changes	
Character	Place the cursor at the choice beginning with that character	

When a popup menu has been moved by means of the $\langle \rightarrow \leftarrow \uparrow \downarrow \rangle$ keys in combination with the $\langle \mathbf{Shift} \rangle$ key, the new position of the menu will be saved in the file TP5008.DEF.

Help screens

The program contains integrated help screens. The screens can be invoked at several places in the program, by pressing function key $\langle \mathbf{F1} \rangle$. The invoked help screen gives information about controlling the active program part or information about the active program part.

Program settings

Several parts of the program are configurable. To do that, activate the choice **SETTINGS** from the main menu. A popup menu will appear.

The contents are partly dependent on the type of graphics card in your PC. If an EGA or VGA card is available, two choices for setting the screen colors and the monitor type are present. If no EGA or VGA card is detected, those two choices will not be present.

Settings concerning the program itself (and not the measuring instruments of the program) are saved immediately in the file TP5008.DEF, which is read at the start of the program.

Saving instrument settings

When the **SAVE** choice is activated all settings of the 5 measuring instruments will be stored in a file to be indicated. The default extension of this file is "SET". At starting the program this file can also be given as parameter.

Loading instruments settings

When the **RESTORE** choice is activated a setting stored by **SAVE** can be restored.

Setting the file type for measurement data

With the choice **SET DATAFILE TYPE** the file type with which the data will be stored on disk can be set. When the **BYTE** option is selected the data file exists of records of 4 bytes (byte 1 and 2 are the value of CH1 and byte 3 and 4 are the value of CH2).

When the **ASCII** option is selected the data file exists of an ascii file of 4 columns, separated by a comma. Column 1 is the sample number, column 2 the sampling time, column 3 the voltage value of CH1 and column 4 is the voltage value of CH2.

Setting the location of files

With the choice **DEFAULT DIRECTORY** the default directories for the TP5008, the print files and the data files can be set. The default directory for the TP5008 is the directory containing the files TP5008.EXE, TP5_ENG.HLP, TP5_ENG.INF and TP5008.FNT.

Setting the default TP5008 address

With the choice **DEFAULT TP5008 ADDRESS** the I/O address the TP5008 is set to can be indicated.

Setting the printer port

With the choice **DEFAULT PRINTER PORT** the parallel printer ports 1, 2 or 3 to be connected to the printer can be selected.



Note Printer port 1 has the I/O address \$3BC, printer port 2 has the I/O address \$378 and printer port 3 has the I/O address \$278.

Setting the printer type

With the **SET PRINTER TYPE** choice you can choose between an **EPSON** compatible matrix printer or an **HP-LASER** compatible printer. This setting is used for printing out data.

Default text on the printer output

With **SET USER TEXT** you can fill in three text lines. These text lines are placed at the top on each print out (with the PRINT option). For example, you can fill in your name and address information in these text lines.

The text lines are saved in the TP5008.DEF file. At the start of the program the text lines are read automatically.

Setting the screen colors

When an EGA/VGA color monitor is available, the colors of the background, the foreground, CH1, CH2 and the cross hair can be set. While changing, the new color is displayed immediately. The color brightness can be changed using the <←→> keys or the mouse.

Also a selection can be made between a color or a black and white display.

Storing measurement data on disk

By activating the **WRITE DISK** choice a file name is requested. A file name without extension has to be entered. The data are stored in filename.DAT and the corresponding instrument setting in filename.GEG. In case the file name already exists, the program asks to overwrite the existing file. If there is insufficient disk space an error message appears. A file with the extension "DAT" and a file with the extension "GEG" are made during a WRITE DISK. The data format is determined by SET FILE TYPE.









Note The voltmeter has a completely different way of storing measurement data. This will be described in the chapter Voltmeter.

The transient recorder always stores data on disk, so the choice WRITE DISK is not available.

Loading saved measurement data

By activating the choice **READ DISK** a popup menu appears, giving an overview of the data files contained in the indicated default data directory. With the <←↑↓→> keys a file can be selected. When a selection has been made, the data and set files will be read from disk. When the data is not from the measuring instrument only the data file is read, or an error message appears.

The following file operations can be carried out with the function keys:

-  View the file information (size, date and time)
-  View the file (only text files)
-  Delete the file
-  Rename the file
-  Copy the file
-  Enter a new directory mask and/or path and/or disk

When <F4>, <F5> or <F6> is used, both the .DAT file and the .GEG file are acted on.

Printing measured data

There are two ways to print the measurement data.

The first way is pressing <Shift-PrtSc>. A quarter page size screen dump is made, containing only the information that is found on the display.

The second way is activated by the menu choice **PRINT**. A popup menu appears, displaying 2 choices.

The **DISK** choice requests for a file name to create the print file. This print file can be sent to the printer using the DOS command: `COPY/B filename PRN`, where *filename* stands for the file name you entered in the input box.

With the **PRINTER** option the screen can be printed out on an EPSON, HP-LASER or a compatible printer. What printer type has been installed is indicated at the bottom of the popup menu. This printout is full page, containing extra information like date and time of the measurement, the comment lines and the USER TEXT.

Comments can be added to the printout using the **COMMENT** choice. When activated, a dialog box appears, in which three lines of text can be entered. These comments entered here are printed together with a

printout The comments are stored on disk together with the data. So each data file has its own comments. The key <F1> gives an overview of valid function keys in the editor.

Choosing an instrument

By activating the choice **DEVICE**, menu a popup menu appears, displaying 6 choices.

When the **QUIT** choice is activated, the program will be terminated. The other options activate the indicated measuring instrument.

The measuring instruments (the devices) to be selected are:

LIVE	=	oscilloscope
HOLD	=	storage oscilloscope
SPECTRUM	=	spectrum analyzer
VOLT	=	voltmeter
TRANS	=	transient recorder

This menu can also be activated by means of the <Esc> key or the right mouse button (if no other menu is active).

Terminating the program

The popup menu **DEVICE** can be invoked from all program sections by means of the <Esc> key or the right mouse button. The **QUIT** option enables you to leave the program and takes you back to the operating system (DOS). The popup menu **DEVICE** can also be invoked with the <Esc> key or the right mouse button, if no other menu is active.

Chapter 4

Oscilloscope (device: LIVE)


An oscilloscope is a measuring instrument which displays the changes of a voltage in the time domain.

The TP5008 is equipped with an oscilloscope with 2 inputs (channels), of which the sensitivity of each channel is adjusted separately. It is a digital sampling oscilloscope. That means that the oscilloscope takes samples at fixed times. From each sample the value is determined and the size is displayed at the screen. The screen is filled with 480 samples per channel. Between two adjacent samples on the screen a line is drawn. The speed at which the samples are taken, is adjustable.

Aliasing

A disadvantage of digital sampling oscilloscopes is the fact that aliasing can occur.

Aliasing occurs when too low and therefore a wrong sampling speed is chosen. In the next illustration is shown how aliasing occurs.



The input signal is a triangular signal with a frequency of 1.25 kHz (upper most in the illustration). The signal is sampled at a frequency of 1 kHz. The dotted signal is the result of the reconstruction. From that triangular signal the periodical time is 4 ms, which corresponds with an apparent frequency (alias) of 250 Hz (1.25 kHz - 1 kHz).

To avoid aliasing, the sample frequency must be greater than 2 times the maximum frequency of the input signal.

If you have any doubts about the displayed signal, you can set the timebase of the oscilloscope one step faster or slower and check whether the signal at the display changes accordingly. If that does not give any clearance, you can determine the frequency of the input signal with the spectrum analyzer. Therefore you must set the frequency range of the spectrum analyzer to the maximum, to avoid aliasing with the spectrum analyzer. For more information, see the chapter Spectrum Analyzer

Displaying channels

The TP5008 has several modes to display the two channels. The mode can be set by activating the choice **MODE** from the main menu.

By activating MODE a popup menu appears with 6 or 7 options:

CH1	Only CH1 is measured and displayed
CH2	Only CH2 is measured and displayed
ALTERNATE	CH1 and 2 are measured and displayed alternating.
CHOP	CH1 and 2 are measured and displayed simultaneously
ADD	CH1 and 2 are measured simultaneously and added. Only the sum is displayed
COMPARE	CH1 is measured and displayed. The latest measured signal at CH2 is displayed, to compare it with CH1.
XY-PLOT	This is a special display mode. CH1 and CH2 are measured in CHOP mode. CH1 is displayed at the x-axis and CH2 at the y-axis of the screen.



Note When the CHOP or XY-PLOT mode is selected and TIME/DIV is at the fastest option, the second fastest option of TIME/DIV will be taken automatically during measuring.

Setting up a channel

The two channels of the TP5008 oscilloscope are completely configurable. Both channels are identical, each has its own menu in the main menu. Since the possibilities for both channels are equal, only CH1 is explained here. Where CH1 is described, the same applies to CH2.

With the choice **CH1 SET** (or **CH2 SET**) from the main menu a popup menu is called.

With the choices from this menu CH1 can be configured.

Setting the sensitivity of a channel

By activating the choice **VOLTS/DIV** a popup menu appears, displaying 6 voltage ranges.

When e.g. **10** has been activated, a voltage range of 2.5 volts/div will be set, that is, the maximum voltage to be measured is ± 10 volt. The **AUTO** option provides for setting the voltage-axis automatically.


The following ranges can be selected: 0.5, 1, 2, 5, 10 and 20 volt.

Setting the vertical position of a channel

The vertical position of a channel on the screen can be adjusted.

When doing this, the signal is shifted graphically, **after** sampling. This method only has an effect on the displayed signal. If the signal clipped, because it is larger than the selected input range, and is positioned with the software method, the signal remains clipped, but the clipping is now visible on the display. The signal appears to be 'cut off' at either the upper side or the lower side. This positioning method is used for placing two overlapping signals away from each other.

The positioning method is not done by means of a popup menu. At the lefthand side of the screen (in CHOP, ALT, ADD and X-Y for CH2 at the righthand side) two small arrows are visible. The small arrow next to the border of the window is for the position of a channel, the outer arrow is for the trigger level, which is discussed later.



There are two or four arrows, depending on whether one or two channels are displayed. Only one offset (arrow) can be active, displayed normally. All other arrows are displayed inverted. In the above illustration the channel offset arrow for CH 1 is active.

The arrow indicates the offset, the 0 volt level. The offset can be set as follows:



Note To change the offset, first remove all popup menus

SHIFT	↑
SHIFT	↓
SHIFT	home
SHIFT	→
SHIFT	←
SHIFT	page up
SHIFT	page down
SHIFT	+
SHIFT	-

Move the offset level up

Move the offset level down

Move the offset level to the center

Select the next offset or trigger level

Select the previous offset or trigger level

Move the offset level to the top

Move the offset level to the bottom

Increase the step size (2 times)

Decrease the step size (2 times)



Note the step size for changing the offset level or trigger level can be changed with <Shift-+> and <Shift-—>

The offset level can also be changed with the mouse. Place the mouse

cursor on top of the arrow of the offset level to be changed and drag it to the correct position. Drag: press the left mouse button and keep it pressed, while moving the mouse. When the arrow is at the correct position, release the mouse button. The mouse cursor will disappear while dragging the arrow and appear again when the button is released.

Enlarging or reducing the vertical axis

The measured values can be enlarged or reduced by software. Because of that it is possible to magnify the vertical axis. It is also possible to invert the measured values. After activation of the choice **GAIN** in the menu CH1 SET, a dialog box appears in which a multiplication factor can be entered. The factor must be between -5 .. -0.1 or 0.1 .. 5. The measured factors are multiplied by the factors and then displayed. The numbers along the vertical axis are also changed.

The GAIN can be used to invert a signal. Suppose you are measuring two signals and wish to subtract the signal on CH1 from the signal on CH2. To do that you have to set the GAIN for CH1 to -1 and the gain for CH2 to +1. By selecting a measuring mode ADD (CH2 - CH1) is displayed.



Note By choosing a gain of -1, two signals can be subtracted from each other.

An other possibility is displaying two signals of a different size at the same size, to simplify comparison. Suppose you have a 5 volt square wave signal on CH1 and a 4 volt square wave signal on CH2. For displaying both signals at the same size, set the gain for CH1 to 0.8 and for CH2 to 1. Both signals are displayed then at the same size.

Changing the units of the vertical axis

Along the vertical axis, normally the voltage of the input signal is projected. The unit of measure is then Volt and the numbers along the axis correspond with the size of the input signal.

The TP5008 oscilloscope allows you to create another definition of the vertical axis.

By means of the choice **UNIT** from the CH1 SET menu the units of measure of the vertical axis can be changed.

After activation, a popup menu with 11 choices appears. The unit that is selected, is displayed at the top of the vertical axis. It is also placed on the paper when printed out. The possible choices are:
VOLT, AMPERE, DEGREE F, DEGREE C, WATT, PERCENT, METER, KILOGRAM, NEWTON, COLOMB and BAR.

If you are measuring e.g. with a temperature probe, you can choose **DEGREE C** for the units.

By activating the choice **UNITS/VOLT** from the menu CH1 SET, a multiplication factor can be entered for the units of the vertical axis. A dialog box appears in which the factor is entered. The numbers along the vertical axis are multiplied by the factor and replaced by the result.

If you are using a 10x probe, you can by means of UNITS/VOLT enter the value 10, to get correct numbers along the vertical axis.

Another application is the previously mentioned example with the temperature probe. Suppose the temperature probe gives a voltage change of 1 volt at a temperature change of 5 degrees. By entering the factor 5, the temperature change is displayed directly in the number of degrees.

It is also possible to add an offset to the numbers of the vertical axis. In the dialog box called by activating **OFFSET** from the CH1 SET menu, an offset can be entered. This offset is added to **the numbers along the vertical axis**. Nothing is done to the signal.

An application for this is again the temperature measurement. Suppose the output voltage of the temperature probe at 0°C is +10 Volt. By entering a UNITS/OFFSET of -10, the zero level of the axis is changed in a way that the absolute temperature is directly readable.

Setting up the time axis

Along the horizontal axis of the screen the measuring time is projected.

Setting the timebase

By activating the choice **TIME/DIV**, a popup menu appears, displaying 12 time ranges.

When, for example, the **0.2 sec** choice has been activated, one time division will be equal to 0.2 sec. The screen contains 12 time divisions.

One time division consists of 40 samples. The screen contains $12 \cdot 40 = 480$ sample values. By activating the **0.2 sec** choice one sample is taken every $0.2/40 = 5$ msec.

With the **0.2 sec** choice the minimum duration of the sampling process is $12 \cdot 0.2 \text{ sec} = 2.4 \text{ sec}$. When a key is pressed within these 2.4 sec, the sampling process will be interrupted and the program will respond to the key press.

The following time-axis ranges can be selected: 0.2 msec, 0.5 msec, 1 msec, 2 msec, 5 msec, 10 msec, 20 msec, 50 msec, 0.1 sec, 0.2 sec, 0.5 sec and 1 sec.



Note On a XT computer the fastest, and sometimes the second fastest timebase setting as well, will not be available. In the CHOP and XY-PLOT measuring modes the fastest and second fastest timebase settings are equal.

Magnification of the horizontal axis

By activating the **TIME-MAG** choice, a popup menu appears, displaying 12 software time-axis magnification areas.


When, for example, the **2*** choice has been activated, the time-axis will be magnified 2 times. The magnified part of the screen is indicated by two interconnected arrows at the bottom of the screen. The time-axis magnification area can be moved using the **<PgUp>** and **<PgDn>** keys or by mouse. Place the mouse cursor on the interconnected ar-

rows, press the left mouse button and drag the arrows left or right. With the <+> and <-> keys the step size can be increased and decreased, respectively.

The following time-axis magnification areas can be selected: 1, 2, 3, 4, 5, 6, 8, 10, 12, 15, 16 and 20 times.

Triggering

To be able to examine a signal, the moment of displaying the signal has to be adjustable. Therefore an oscilloscope is equipped with a triggering system. This functions as follows:



The input signal is compared with two levels in the trigger circuitry: the arming level and the firing level. When the input signal passes the arming level, the trigger system is armed. If the the input signal passes the firing level, the trigger system becomes active and 'fires' a pulse. This pulse is used to start the display of the signal.

The arming level and the firing level are coupled to each other by the trigger hysteresis and their level is determined by the trigger level. The firing level corresponds to the trigger level. The trigger hysteresis defines at which signal size change can be triggered, the change has to be that large that both levels are passed. With a small trigger hysteresis it is possible to trigger on small signals. If a signal contains a lot of noise, a small trigger hysteresis causes triggering on the noise, instead of the original signal, which gives an unstable display. A trigger hysteresis larger than the noise level is then necessary.

In the latter illustration a signal and the two levels are displayed. In this case it is triggered on the rising slope of the signal. The signal passes the two levels from low to high. When triggering on the falling slope of a signal, the two levels are swapped. Then the signal has to pass the two levels from high to low, to generate a trigger.

Selecting the trigger source

By activating the **TRIG CH1 / TRIG CH2** choice, the text in the menu changes from TRIG CH1 to TRIG CH2 or vice versa.

In the TRIG CH1 position triggering takes place on CH1 and in the TRIG CH2 position on CH2.

Setting the trigger hysteresis

By activating the choice **HYSTERESIS**, a popup menu appears, displaying 12 trigger hysteresis options.

For example, when the **0.5 DIV** option has been activated, the trigger hysteresis will be 0.5 division of the voltage range set. This means that the signal has to come out at a minimum of 0.5 division below the trigger level set (for a positive trigger slope). When the signal has much noise the trigger hysteresis can be set high to ensure that triggering is satisfactory.

When a signal has less noise, the trigger hysteresis can be set low allowing triggering at low signal levels. For setting the trigger level, see: offset and trigger levels.

The following trigger hysteresises can be selected: 0 DIV, 0.125 DIV, 0.25 DIV, 0.5 DIV, 0.75 DIV, 1.0 DIV, 1.25 DIV, 1.5 DIV, 1.75 DIV, 2.0 DIV, 2.25 DIV and 2.5 DIV.

Setting the trigger slope

By activating the choice **SLOPE+ / SLOPE-**, the text in the menu choice changes from SLOPE+ to SLOPE- or vice versa.

In the SLOPE+ position triggering takes place on a rising slope of the signal to be measured and in the SLOPE- position on a falling slope.

Adjusting the trigger level

The adjustment of the trigger level is not done by means of a popup menu. At the lefthand side of the screen (in CHOP, ALT, ADD and X-Y for CH2 at the righthand side) two small arrows are visible. The small arrow next to the border of the window is for the position of a channel, the outer arrow is for the trigger level.

There are two or four arrows, depending on whether one or two channels are displayed. Only one arrow can be active, displayed normally. All other arrows are displayed inverted. The arrow indicates the trigger level. The trigger level can be set as follows:



Note To change the trigger level, remove all popup menu's

SHIFT	↑	Move the trigger level up
SHIFT	↓	Move the trigger level down
SHIFT	home	Move the trigger level to the center
SHIFT	→	Select the next offset or trigger level
SHIFT	←	Select the previous offset or trigger level
SHIFT	page up	Move the trigger level to the top
SHIFT	page down	Move the trigger level to the bottom
SHIFT	+	Increase the step size (2 times)
SHIFT	-	Decrease the step size (2 times)



Note the step size for changing the offset level or trigger level can be changed with <Shift-+> and <Shift-—>

The trigger level can also be changed with the mouse. Place the mouse cursor on top of the arrow of the trigger level to be changed and drag it to the correct position. Drag: press the left mouse button and keep it pressed, while moving the mouse. When the arrow is at the correct position, release the mouse button. The mouse cursor will disappear while dragging the arrow and appear again when the button is released.

Setting the trigger time-out

When the input signal does not meet the trigger conditions, no new measurement data will be displayed and the last displayed signal will remain on the screen. This can be very inconvenient with unknown signals, since it is not known how the trigger circuitry has to be set. To provide in that case for a representation of the input signal on the screen, a trigger time-out setting is available.

With the time-out setting it is determined how long the delay will be for a trigger pulse. If that time expires, the available data will be displayed. This will not result in a stable display, but it will give an impression how the trigger has to be set.

By activating the choice **TIME-OUT** from the main menu, a popup menu appears with 12 choices for the trigger time-out: 0 DIV, 10 DIV, 20 DIV, 50 DIV, 100 DIV, 150 DIV, 200 DIV, 250 DIV, 300 DIV, 350 DIV, 400 DIV and 1600 DIV.

For example, when the **50 DIV** option has been activated, the signal will be controlled for 50 time divisions maximally. If the signal does not comply with the trigger level set, the trigger slope and the trigger hysteresis within 50 time divisions, it will nevertheless be measured after 50 time divisions.

Stopping the display

By activating the **LIVE/FREEZE** choice, the text in the menu changes from LIVE to FREEZE or vice versa.

In the LIVE position the oscilloscope continuously takes 480 samples and displays them on the screen.

In the FREEZE position no samples are taken and the samples last taken are displayed on the screen. A **ONE SHOT** menu is added in the FREEZE position.

By activating the **ONE SHOT** menu the text in the menu changes from **ONE SHOT** to **MEASURE**. After measuring the signal the text changes back to **ONE SHOT**. When a key is pressed during measuring (MEASU-

RE), the sampling process will be terminated immediately. Samples taken up to the moment the key is pressed can be viewed (the remaining samples are 0).

Magnifying a part of the screen

By activating the choice **ZOOM**, a popup menu appears, displaying 2 options.

The **FULL** choice displays the signal fully. (The x-axis and y-axis magnifications are set at 1 and the offset levels at 0.)

With the **WINDOW** option a rectangular magnification area can be indicated using the <←↑↓→> keys or the mouse. One corner has to be indicated first, followed by the <Enter> key or the left mouse button. Then the second corner has to be indicated, followed by the <Enter> key or the left mouse button. Cancelling the zooming can always be done by means of the <Esc> key or the right mouse button.

Differences with the oscilloscope

























The storage oscilloscope HOLD is quite similar to the oscilloscope LIVE, there are a few differences, which will be described here. For the rest is referred to the chapter Oscilloscope (LIVE).

- The HOLD scope only works in ONE SHOT mode and does not measure 1 but 10 pages of 480 samples. With the <PgUp> and <PgDn> keys, the pages are selected. The step size can be set using the <+> or <-> keys.
- The HOLD scope does not provide for XY-PLOT
- After measuring, a cross hair appears, to simplify voltage and time measurements

The main menu of the HOLD device differs slightly from the main menu of the LIVE device. At the position where in the LIVE device the LIVE / FREEZE choice is found, the HOLD device has a choice ONE SHOT.

Measuring with the cross hair

After the measured signal is displayed, a crosshair appears. With the crosshair absolute and relative time and voltage measurements can be performed. Controlling the crosshair is done with the following keys:

		Setting the absolute zero
		Setting the relative zero
		Move the crosshair to zero
		Move the crosshair up
		Move the crosshair down
		Move the crosshair to the left
		Move the crosshair to the right
		Mirror the crosshair on the relative x-axis
		Mirror the crosshair on the relative y-axis
		Decrease the step size twice
		Increase the step size twice
		Switching between crosshair controll and offset/ trigger level controll.

Absolute zero is that point at the screen where voltage and time are zero (left most, in the center of the screen). Relative zero is that point set by moving the crosshair to the intended point and subsequently pressing **<Shift-Del>**.


The time and voltage values according the crosshair position are displayed on the screen, the voltage value in the upper right corner of the screen and the time value at the right most end of the time axis. The values are displayed inverted.

The crosshair can also be moved by means of the mouse. This is done by placing the mouse cursor at the crosshair, press the left mouse button and move the mouse, keeping the left mouse button pressed. While positioning the crosshair with the mouse, the mouse cursor disappears. When the correct position is achieved, the left mouse button can be released and the mouse cursor appears again.

The (storage)oscilloscope measures and displays signals in the time domain: the voltage is plotted against the time. It is also possible to display measurement data in the frequency domain, the data is then plotted against the frequency. For this method the spectrum analyzer is used.

Description of FFT

The spectrum analyzer is using the Fast Fourier Transform (FFT) principle. For this transform, 1024 samples are taken with a previously set sample speed. With these 1024 samples, here called FFT-block, the spectrum is calculated. Therefore the FFT places an infinite number of FFT-blocks behind each other, in the positive and negative direction. Each FFT-block forms 1 period of the created periodic signal.




From the signal obtained like this, the spectrum is calculated. The FFT calculation results in 512 spectral components. These spectral components together form the frequency spectrum of the input signal. 480 of the 512 spectral components are displayed, in 12 divisions of 40 spectral components each.

The TP5008 spectrum analyzer displays an amplitude spectrum, which means that a 2 volt peak-peak sine wave is displayed with a 1 volt spectral component.

Aliasing


Like the oscilloscope, the spectrum analyzer needs a high enough sampling frequency to avoid aliasing. The result of aliasing when using FFT is that the frequency curve is folded back on itself. See also the next illustration.



The original signal is sampled at a sample time Δ . The critical frequency (Nyquist frequency) is $(1/2\Delta)$ Hz.


Windowing

FFT treats the FFT-block of 1024 samples like it is one period of a periodic signal. If the sampled signal is not periodic, harmonic distortion can arise, since the periodic waveform, 'created by the FFT', can have sharp discontinuities. See also the following illustration. These discontinuities are also called calculation errors.



This means that because of the calculation errors extra frequency components are generated around the true frequency. Because of this 'smearing' the amplitude of the true frequency decreases, since the area under the curve remains the same.


The smearing, caused by the calculation errors, can be decreased by placing a window on the FFT-block of 1024 samples, in such a way that the ends of the FFT-block are smoothly tapered to zero and discontinuities do not occur when the FFT treats the windowed block as one period of a periodic signal. Each sample of the FFT-block is therefore multiplied by a factor, whose size is dependent on the position of the sample in the FFT-block. See also the following illustration.




The software supports five different windows:

- rectangular (all data remains the same)
- Hanning
- Hamming
- Blackman
- Bartlett


A graphical representation of the different windows is given in the next illustration.




The effects of the different windows are displayed next, together with the sinewave signal the spectrum is taken from. The sinewave does not fit in the FFT-block and will therefore cause calculation errors.




The measured sine wave




Rectangular window




Hanning window



Hamming window




Blackman window




Bartlett window

When using the rectangular window, the amplitude of the spectrum is lower than with the other windows. Smearing is larger with the rectangular window.


Again some example illustrations, now with a sine wave exactly fitting in the FFT-block.




The measured sine wave




Rectangular window




Hanning window



Hamming window



Blackman window



Bartlett window

Similarities with the oscilloscope

The spectrum analyzer has some similarities with the oscilloscope. The bottom row in the main menu contains choices that are similar to the ones in the oscilloscope devices. They will not be discussed here.

Displaying channels

The spectrum analyzer has several ways to display the two channels. By activating **MODE** from the main menu, a popup menu containing five choices appears. The spectrum analyzer does not have the display option X-Y PLOT. The other choices are equal to the choices for the oscilloscope. See the chapter Oscilloscope for an explanation of the possibilities.

Setting up a channel

The two channels of the spectrum analyzer can be set up to your own demands. For both channels equal settings are available, each through their own choice in the main menu. The available settings are equal to the settings for the oscilloscope channels, except for a few points. These points will be discussed here, the other points will be referred to the chapter about the oscilloscope. All that is discussed here, is valid for both channels.

Activating the choice **CH1 SET** from the main menu, gives a popup menu which is almost equal to that of the oscilloscope, except for the last line. The oscilloscope provides for a choice **UNIT**, the spectrum analyzer for a choice **LINEAR/dB**.

Setting the sensitivity

The sensitivity of a channel can be set in exactly the same way as with the oscilloscope. It can be done by means of the choice **VOLTS/DIV**.

Adapting the vertical axis

With the spectrum analyzer you can decide whether the vertical axis will be linear or logarithmic. This is done with the setting **LINEAR** or **dB** from the menu CH1 SET. The current setting is displayed by the text of the choice. Activating the choice will make the text and setting change.

On a logarithmic axis, 0 dB corresponds with 1 Volt.

Setting up the frequency axis

By activating the choice **FREQUENCY**, a popup menu appears, displaying 12 frequency ranges.

For example, when the **1200 Hz** option is activated, the maximum frequency displayed by the spectrum analyzer will then be 1200 Hz. The resolution is $(1200\text{Hz}/480) 2.5 \text{ Hz}$.

The following frequency ranges can be selected: 24 Hz, 48 Hz, 120 Hz, 240 Hz, 480 Hz, 1200 Hz, 2400 Hz, 4800 Hz, 12 kHz, 24 kHz, 48 kHz and 80 kHz.



Note On a XT computer, the highest, and sometimes the second highest frequency range are not available. In ALT and CHOP mode, the highest frequency range equals the second highest frequency range.

Magnifying the frequency axis

By activating the **FREQ-MAG** choice, a popup menu appears, displaying 12 magnification areas.

When, for example, the **2*** option has been activated, the frequency-axis will be magnified 2 times. The magnified part of the screen is indicated by two interconnected arrows at the bottom of the screen.

The frequency-axis magnification area can be moved using the **<PgUp>** and **<PgDn>** keys or the mouse by placing the mouse cursor on the interconnected arrows and clicking the left mouse button (while moving

the mouse button must be kept pressed). With the <+> and <-> keys the step size can be increased and decreased, respectively.

The following frequency-axis magnification areas can be selected: 1, 2, 3, 4, 5, 6, 8, 10, 12, 15, 16 and 20 times.

Selecting the window

By activating the choice **WINDOW**, a popup menu appears, displaying 5 window types.

These windows are used to reduce calculating errors during the FFT transformation. See at the beginning of this chapter for an explanation about FFT and windows.

The following window types can be selected: rectangle(= no window), Hanning, Hamming, Blackman, Bartlett.

Averaging of spectra

When the spectrum of a non-periodic signal (for example noise) is measured, **AVERAGE** can be used.

By activating the choice **AVERAGE**, a popup menu appears, displaying 8 options. When **AVERAGE** is set to 10, 10 spectra will be measured, calculated and averaged. After calculating each spectrum the results are displayed immediately. The averaging process can be interrupted by pressing the <**Esc**> key or the right mouse button.

The following choices for averaging are available: 1, 2, 5, 10, 20, 50, 100 and 200.

Starting a spectrum measurement

The sampling process is started by activating the choice **MEASURE**.

On the screen the text "MEASURING, PLEASE WAIT ..." appears. After the sampling process the spectrum is calculated using FFT and the message "CALCULATE SPECTRUM 1, PLEASE WAIT ..." (Esc; Exit) appears on the screen. When there are more calculations set by means of the **AVERAGE** menu, the first text will be displayed on the screen followed by the second one.

Measuring a harmonic distortion

By activating **DISTORTION**, a frequency can be indicated by means of the <←↑↓→> keys or the mouse.

The indicated frequency is considered the fundamental frequency.

The total harmonic distortion relative to this fundamental frequency is determined on the basis of the formula:

$$\log \frac{\sqrt{V_2^2 + V_3^2 + V_4^2 + V_5^2 + V_6^2 + V_7^2 + V_8^2 + V_9^2 + \dots}}{V_1}$$

V_1 is the RMS amplitude of the fundamental frequency. $V_2 \dots V_{10}$ are the RMS amplitudes of each harmonic. The RMS amplitude of each harmonic is shown in a table.

Calculate the spectrum from the HOLD signal

By activating **HOLD->FFT**, the spectrum of the first 1024 measuring points of the signal measured with the HOLD device is calculated. The frequency-axis and the voltage-axes are adjusted to the value of the HOLD device.

Chapter 7

Voltmeter (device: VOLT)

The TP5008 is equipped with a two channel voltmeter with digital display.

The voltmeter functions as follows:

- 200 points are sampled.
- The measured data is processed, e.g. for calculating the RMS value or the mean value. 9 options can be carried out.
- The calculated values are displayed, e.g. add CH1 and CH2 and display on CH1. 16 different display modes are available.

Because of the computations and display modes there are many options (± 100) to measure a signal with the voltmeter.

Setting up a channel

As noticed, the channels can be configured in many ways. Both channels have equal settings, so only CH1 is discussed here. Activating the choice **CH1 SET** brings up a popup menu in which the settings for CH1 are available.

Setting the input range

By activating the **VOLTS/DIV** choice, a popup menu appears, displaying 6 voltage ranges.

When the **10** option has been activated, a sensitivity of ± 10 volt full scale will be set. This corresponds with 2.5 V/div. The **AUTO** option provides for setting the voltage-axis automatically.

The following voltage ranges can be selected: 0.5, 1, 2, 5, 10, and 20 volt.

Changing the units of measure

The units of measure displayed, can be configured to your own demands. By activating the choice **UNIT**, a popup menu with the choices. When the requested option is activated, this unit will be placed under the display behind the MEASURING mode. At an ACQUIRE TO DISK (or an ACQUIRE TO PRINTER) the unit is placed behind the MEASURING mode as well.

Changing the units per volt

By activating the choice **UNITS/VOLT**, you can enter a factor for the display. The value filled in will be multiplied with the measured value.

Example: A thermocouple generating 1 volt per 5 degrees is measured. Then the number of UNITS/VOLT can be set at 5 allowing the direct reading of the correct number of degrees.

When an oscilloscope probe which attenuates 10 times is used, the value 10 can be entered with the UNITS/VOLT option, so the correct voltage values can be read directly.

Relative measurements

By activating the **RELATIVE = ON/OFF** choice, the text changes from RELATIVE = ON to RELATIVE = OFF or vice versa.

The RELATIVE = ON option results in decreasing the displayed value with the value given at the SET REL. VALUE option.

Example: MEASURING is set on MEAN and DISPLAY is set on CH 1. When a DC voltage of 10 volt is offered, the voltmeter will point at 10 volt. When the value 10 is filled in with the SET REL. VALUE option and RELATIVE = ON is set, the voltmeter will point at 0 volt.

With the RELATIVE = OFF option the measured value is not influenced.

Comparison measurements

For displaying the measured and calculated values, 16 methods are available. Four of those methods are comparison measurements:

- > then HI
- < then LO
- > < COMP
- < > LO HI

These measurements require a HIGH and a LOW value. With the choices **SET HIGH VALUE** and **SET LO VALUE** the two values can be set. Activating the choices will bring up a dialog box in which the size of the level can be entered in volts.

Setting the impedance

The dBm and POWER measurements require a reference resistance. The value of the resistance can be set by activating **SET IMPEDANCE** from the CH1 SET menu.

The value has to be entered in Ohm. The default value is 600 Ω .

Setting the gate time

By activating the choice **SET GATE TIME**, a gate time value can be selected. The gate time set is used for measuring the frequency. When the gate time is set at 0.1 sec, the measuring time is 0.1 sec and the frequency resolution 10 Hz. At a gate time of 1 sec the frequency resolution is 1 Hz and determining the frequency takes 1 sec. The voltmeter will then respond less quickly on the key board and the mouse.

Processing the measured data

By activating **MEASURING**, a popup menu appears, displaying 9 calculations.

The option chosen determines how the data of CH1 (or CH2) will be calculated.

The following options can be selected:

True RMS: The true RMS value of the sampled data is calculated. The true RMS value (Root Mean Square) is the value of a casual voltage form, identical to a DC voltage dissipating the same power in a resistance.

An AC voltage of 1 volt (RMS) is identical to a DC voltage of 1 volt. (Most -cheap- voltmeters only point the right value at a true sine voltage when an AC voltage is measured. The TP5008 always points the correct value at the true RMS handling.)

PEAK TO PEAK

The peak to peak voltage of the sampled data is determined. The peak to peak voltage of a DC voltage is zero. The peak to peak voltage of a true sine with a RMS value of 1 volt is 2.828 volt.

MEAN:

The mean value of the sampled data is determined. The mean value of the DC voltage of 1 volt is 1 volt. The mean value of a true sine with a RMS value of 1 volt is 0 volt.

MAX:

The maximum value of the sampled data is determined. The maximum value of a DC voltage of 1 volt is 1 volt. The maximum value of a true sine with a RMS value of 1 volt is 1.41 volt.

MIN:

The minimum value of the sampled data is determined. The minimum value of a DC voltage of 1 volt is 1 volt. The minimum value of a true sine with a RMS value of 1 volt is -1.41 volt.

dBm:

The value of the sampled data is converted into decibels. Converting is done by means of the formula:

$$dBm = 10 * \log \frac{1000 * value^2}{reference\ resistance}$$

With "value" the RMS value of the measured data is meant. The reference resistance can be set with the SET IMPEDANCE option.

POWER: The value of the sampled data is converted into a power. Converting is done by means of the formula:

$$POWER = \frac{value^2}{reference\ resistance}$$

With "value" the RMS value of the measured data is meant. The reference resistance can be set with the SET IMPEDANCE option.

CREST: The value of the sampled data is converted into a crest factor. Converting is done by means of the formula:

$$CREST = \frac{peak\ value}{RMS\ value}$$

The "peak value" is the peak voltage relative to the zero line of the signal.

FREQ: The frequency of the offered signal is determined. The accuracy and the speed of calculating the frequency is determined by the "gate time".

Displaying the measured value

By activating the **DISPLAY** choice, a popup menu appears, displaying 16 options.

The option chosen determines how the data of CH1 or CH2 will be displayed. The options are:

CH1: Display data of CH1.

CH2: Display data of CH2.

CH1*CH2: Display data of CH1 multiplied with data of CH2.

CH1/CH2: Display data of ch 1 divided by data of CH2.

CH2/CH1: Display data of ch 2 divided by data of CH1.

CH1-CH2: Display data of ch 1 minus data of CH2.

CH2-CH1: Display data of ch 2 minus data of CH1.

CH1+CH2: Display data of ch 1 plus data of CH2.


> then: The data is compared with the HIGH VALUE. When the data is higher than HIGH VALUE, **PASS** is displayed. When the data is smaller than HIGH VALUE, **LO** is displayed.

- < then:** The data is compared with the LOW VALUE. When the data is lower than LOW VALUE, **PASS** is displayed. When the data is higher than LOW VALUE, **HI** is displayed.
- >< COMP:** The data is compared with the LOW VALUE and the HIGH VALUE. When the data is higher than HIGH VALUE, **HI** is displayed. When the data is lower than LOW VALUE, **LO** is displayed. When the data is lower than or equal to HIGH VALUE **AND** higher than or equal to LOW VALUE, **PASS** is displayed.
- <> Hi Lo:** The data is compared with the LOW VALUE and the HIGH VALUE. When the data is higher than HIGH VALUE, **PASS** is displayed. When the data is lower than LOW VALUE, **PASS** is displayed. When the data is lower than or equal to HIGH VALUE **AND** higher than or equal to LOW VALUE, **LO** is displayed.
- MAX:** Display the maximum value of the data.
- MIN:** Display the minimum value of the data.
- LOG(1/2):**
- $$20 * \log \frac{\textit{measured value CH1}}{\textit{measured value CH2}}$$
- LOG(2/1):**
- $$20 * \log \frac{\textit{measured value CH2}}{\textit{measured value CH1}}$$

Setting the frequency range

The voltmeter has a limited frequency range in which the measurements are performed correctly. This is caused by the fact that the voltmeter takes 200 samples, using a certain sampling frequency.

If the periodical time of the input signal is much larger than the measuring time, a wrong value is measured. See the next illustration.



If the time in which the 200 samples are taken is too short in relation to the periodical time of the input signal, **aliasing** can occur (see also the chapter about the oscilloscope).

To avoid errors like the one mentioned above, the frequency range of the voltmeter has to be set properly. The sampling frequency is then changed. By activating the **FREQUENCY** choice, a popup menu appears, displaying 7 center frequencies. A frequency range is determined from $0.2 \times f_{\text{center}}$ to $10 \times f_{\text{center}}$.

For example, when **50 Hz** is chosen, signals with a frequency between 10Hz to 500 Hz will be calculated correctly.

The following center frequencies can be selected: 10 Hz, 50 Hz, 100 Hz, 500 Hz, 1 kHz, 5 kHz and 10 kHz.

Zeroing the voltmeter

The **CALIBRATE** choice allows the zeroing of the voltmeter. By activating CALIBRATE, the following text appears on the screen

Connect probe input to ground and press key (Esc: Exit)

When a key is pressed, the mean value of all input voltage ranges will be measured. This value will be subtracted from the following measurements.

Perform measurements

By activating the **MEASURE/FREEZE** choice from the main menu, the text in the menu changes from MEASURE to FREEZE or vice versa.

In the MEASURE position 200 sample values are taken and from that a determined quantity will be calculated. The quantity to be determined can be set with the CH1 SET menu, MEASURING option. The last measured values are displayed in the FREEZE position.

By activating the choice **ONE SHOT** from the main menu one measurement is taken and from that the data will be calculated and displayed. This menu is only available when the MEASURE/FREEZE choice is in the FREEZE position.

Storing measurement values on disk or paper

The voltmeter can store measurement values on disk or print them on paper. This is done in a completely different way to the other instruments.

The voltmeter can be set to measure (acquire) at fixed times. The measured value will then be stored on disk or sent to the printer.

Setting the time between two measurements

By activating the choice **TIME** from the main menu, the time between two measurements can be set. A dialog box appears in which the time can be entered, in seconds. The time has to be between 0 and 300 seconds.



Note When a time **shorter than 0.5 seconds** is entered, the acquisition speed is determined by the changes of display 1 or display 2. Each time a measurement value at the screen changes, the measured value is stored on disk or printed.

Start an acquisition

By activating the choice **ACQUIRE**, a popup menu is displayed, from which a selection can be made whether the data has to be stored on disk or sent to the printer.

The choice **DISK** will cause the measurement data to be stored on disk. After activating the choice, a dialog box appears in which a name for the file has to be entered. If a file with that name exists, you will be asked whether that file can be overwritten. The data in that file will be lost. After confirmation, measuring starts. At the fixed times a measurement is taken and stored on disk. Measuring can be cancelled by pressing <**Esc**>.

The choice **PRINTER** will cause the measurement data to be sent to a printer. After activating, measuring starts. At the fixed times a measurement is taken and the value is sent to the printer. Measuring can be cancelled by pressing <**Esc**>.

In both modes, the measurement values are preceded by a block of information. In that block is indicated how the channels are set and how the HIGH, LOW and RELATIVE LEVELS are set. Each measurement is preceded by the time and date of the measurement.

If a measured value is higher than the selected input range, '-----' is displayed. This will also be stored on disk or printed.

Changing the display characters

By activating the **DIGIT SET** choice, a popup menu appears, displaying 6 digit thicknesses.

For example, when the **4-PIXELS** choice has been activated, the digit thickness will be 4 pixels.

The following digit thicknesses can be selected: 2, 4, 6, 8, 10 and 12 pixels.

The transient recorder is a two channel, direct registering measuring instrument, displaying the changes of the input signal graphically on the screen or on paper.

The transient recorder measures at settable, fixed times and processes the measured value if necessary. The number of measurements to be taken is also settable.



Note The transient recorder displays a measured sample immediately, the oscilloscope takes all samples and then displays the complete page.

The transient recorder main menu has several items that are similar to the oscilloscope, therefore they are not discussed in this chapter.

Setting the measuring type

By activating **MEAS. MODE**, a popup menu appears, displaying 5 measuring methods.

MOMENTAL	the momentary value will be measured
true RMS	the true RMS (= effective) value will be measured
MEAN	the mean value will be measured
MAX	the maximum value of the signal will be measured
MIN	the minimum value of the signal will be measured

The true RMS, MEAN, MAX and MIN values are calculated from ± 200 samples. To avoid measuring errors the frequency of the measured signal must be around the center frequency set (See also Setting the frequency range in the chapter Voltmeter).



Note When true RMS, MEAN, MIN or MAX is selected, the minimum sampling time will be 0.5 sec.

Setting the frequency range

By activating the **FREQUENCY** choice, a popup menu appears, displaying 7 center frequencies. A frequency range is determined from $0.2 \times f_{\text{center}}$ to $10 \times f_{\text{center}}$.

For example, when the **50 Hz** option has been activated, the signals with a frequency of 10 Hz to 500 Hz will be calculated correctly.

The frequency setting is only effective when True RMS (= effective), MEAN, MAX or MIN values are measured.

The following center frequencies can be selected: 10 Hz, 50 Hz, 100 Hz, 500 Hz, 1 kHz, 5 kHz and 10 kHz.



Note When the 10 Hz center frequency has been selected the minimum sampling time will be 1.5 sec.

Setting the sampling time

By activating **SAMPLE TIME** the sampling time between two measured values can be given.

For the sampling time a value between 0.01 and 300 sec can be given. Then the total measuring time can be $300 \times 30,000 = 9,000,000$ sec (= 104.16 days).



Note On a PC-XT the minimum sampling time is 0.05 sec.



Note When no momentary values are taken (see MEAS. MODE) the minimum sampling time is 0.5 sec, or 1.5 sec at a frequency setting of 10Hz

Setting the number of samples

By activating the **SAMPLES** menu, the number of samples can be given. For the number of samples a value between 1 and 30,000 can be given. Then the total measuring time can be $300 \times 30,000 = 9,000,000$ sec (= 104.16 days).

Clear the screen

By activating the **CLEAR SCR** choice, the screen of the transient recorder is erased.

Start a measurement

When all settings are set, a measurement can be started, by activating **MEASURE** from the main menu. First a name has to be entered for the file the data will be stored in. If the name of an existing file is entered, you will be asked whether this file can be overwritten by the new data. The old data will be destroyed.

When the name is entered, sampling starts. This is indicated by a window with the text:

MEASURING..., **Esc: interrupt measuring.**

At fixed times a sample is taken, until the number of samples to be taken is reached. While sampling, the sample number, the time and the measured value are displayed inverted.



Note When the TP5008 is used in a relative slow computer, it may occur that, depending on the selected sampletime, the sample number, time and value are not being displayed. Only if enough time is available, the items are displayed.

When the total measurement time is completed, the window with the text disappears and the data is saved on disk.

A crosshair, used for measuring, now appears. See the chapter oscilloscope HOLD for information about controlling the crosshair. During measuring with the crosshair, the value, the sample number and the time of the selected sample are displayed.

When more than 480 samples are taken, the keys <PgUp> and <PgDn> provide switching between the pages with data. The current page number is displayed in the upper right corner of the screen. With <+> and <-> the step size can be changed, <+> increases the step size, <-> decreases the step size.

As with the oscilloscope, the data can be shifted up and down on the screen. This is done in the same way as with the oscilloscope.



Note When switching between pages of data, or shifting the signal, each time the complete signal is read from disk, which may take some time.

Go to a specific sample

By activating the **GO TO** choice a sample number to be jumped to can be given. For example, when a measurement has been made involving 15,000 values, then the 15,000th sample value can be jumped to straight away by entering 15,000.

Chapter 9

Programmable signal generator

Installing the software

The signal generator is found on diskette 2. This software can be placed in the same directory as the measurement software.

After copying the files, an install program has to be run to set the basic IO address of the TP5008 in the software. After that is done, the program is ready to use.

The program is started with the command

```
GEN
```

This starts the program.

Setting up the signal

After starting the program you will then see a menu in which you can set all characteristics of the signal you want to generate. Now follows a short description of all settings.

Waveform

With this choice the shape of the signal can be set. Possible choices are: DC, Sine, Block, Triangle, Sawtooth and Noise.

Amplitude

With this choice the amplitude of the signal can be set. Through a popup menu an amplitude can be chosen between 0 and 2.52 Volt.

Number of periods

Internally in the software this parameter is used to generate the signal. An array will be filled with the number of periods that are set here. Possible values lie between 1 and 60. The number of periods has effect on the frequency and resolution of the signal to be generated; the more periods, the higher the frequency of the signal and the lower the resolution of the signal.

Frequency

This choice determines the frequency of the signal to be generated. This setting is dependent on the number of periods that are set. The frequency can be set between 8.13 Hz (1 period) and 49612.5 Hz (60 periods). This is also dependent on the speed of the PC, a PC or PC-XT will have lower highest frequencies than e.g. a 90 MHz Pentium based computer.

Symetry

With this option the symetry of the signal can be set between 1% and 99%.

Envelope

The generator is capable of Amplitude Modulation of the output signal. The signal kind to modulate with, the envelope, can be set with the option Envelope. Possible choices are: DC, Sine, Block, Triangle, Sawtooth, Noise and No Signal (= no modulation).

Envelope amplitude

This option sets the amplitude of the envelope signal. The amplitude can be set between 0 and 2.52 Volt.

Envelope periods

This option sets the number of periods of the envelope signal. This value determines the frequency of the envelope signal. When the number of periods of the normal signal is set to 1 and the number of envelope peri-

ods is set to 5, the envelope signal has a 5 times higher frequency. Possible choices are 1 to 60.

DC level

To the output signal a DC offset can be added, between -2.52 and 2.56 Volt.

Burst ratio

The output can be switched off and on periodically, to generate bursts. The **Burst ratio** option determines how long the signal will be on and off. If the Burst ratio is set to 5, the signal will be **number of periods** on and 5 x **number of periods** off.

Generating the signal

With the choice **Go** the signal is generated. In an oscilloscope-like display one period of the generated signal is displayed.

The generation can be stopped by pressing <**Ctrl-Break**> or by pressing <**Ctrl-Scroll Lock**>. The the main menu will appear again.

Ending the generator program

With the choice **Quit** the program is ended and you will return to the operating system.

Short description

The TP5008 is an 8 bits interface card with two analogue inputs and an analogue output.


The TP5008 contains an 8 bits A/D convertor with a conversion time of 2 μ sec and an 8 bits D/A convertor with a conversion time of 1 μ sec. The TP5008 contains a SAMPLE AND HOLD function.

The voltage range of the two analogue inputs can be set from 0.5 volt (resolution is 4 mvolt) to 20 volt (resolution is 156 mvolt) bipolar. The input impedance is 1 M Ω /20 pF. The input voltage can be coupled through both AC and DC.

The analogue output has two output ranges: 2.5 volt (resolution 20 mV) and 5 volt (resolution 40 mV). The output impedance is 50 Ω .

The TP5008 can be placed in any free ISA slot in an IBM compatible PC, XT or AT.

Connections




At the back of the TP5008 three BNC connectors and two switches are placed. The upper BNC connector is the input for channel 1, the middle BNC connector is the input for channel 2 and the lower BNC connector is the analogue output.

The upper switch is the signal coupling switch for channel 1. The lower switch is the signal coupling switch for channel 2. The upmost position of both switches is AC coupling, the middle position is GND coupling and the downmost position is DC coupling.

In DC coupling, all of the input signal is passed through to the AD convertor. In AC coupling only the AC component of the input signal is passed through to the AD convertor, blocking the DC component. Signals with a frequency lower than approximately 4 Hz are not passed through correct in AC coupling. In GND coupling, the input of the AD convertor is connected to ground, meaning that nothing is measured.

Hardware diagram



Description of the hardware

The TP5008 contains a very fast A/D-D/A convertor. When a value is read at the basic I/O address of the TP5008 (default factory setting is \$308) a conversion is started. During the conversion cycle ($< 2 \mu\text{sec}$) the processor will be put in a "wait state" (through I/O CH RDY). After completing the conversion the processor will take over the conversion cycle value.

The advantage of this method is that you do not have to check whether the conversion is ready or not.

The value generated by the A/D convertor is in 2's complement, see the table.

output value A/D convertor	input value channel 1 or channel 2
0111 1111	factor* $\frac{127}{128}$
0111 1110	factor* $\frac{126}{128}$
0000 0001	factor* $\frac{1}{128}$
0000 0000	0 volt
1111 1111	- factor* $\frac{1}{128}$
1000 0001	- factor* $\frac{127}{128}$
1000 0000	- factor* $\frac{128}{128}$

"Factor" depends on the amplifier settings for Channel 1 and 2.

Setting the input sensitivity

The basic input sensitivity of channel 1 and 2 is 0.5 volt (1 volt peak to peak). The amplifiers of channel 1 and 2 can be set through the basic IO address + 1 (default is address \$309).

The setting byte has the following lay out:

- D0 : low, channel 1 and 2 are amplified 2 times.
high, channel 1 and 2 are amplified 1 time.
- D1 : low, channel 1 is amplified 10 times.
high, channel 1 is amplified 1 time.
- D2 : low, channel 1 is amplified 2 times.
high, channel 1 is amplified 1 time.
- D3 : not used.
- D4 : low, channel 2 is amplified 10 times.
high, channel 2 is amplified 1 time.
- D5 : low, channel 2 is amplified 2 times.
high, channel 2 is amplified 1 time.
- D6 : low, channel 1 is off.
high, channel 1 is on.
- D7 : low, channel 2 is off.
high, channel 2 is on.

input value	factor value for channel 1	input value	factor value for channel 2
01xx x000	0.5 volt	1000 xxx0	0.5 volt
01xx x001	1.0 volt	1000 xxx1	1.0 volt
01xx x101	2.0 volt	1010 xxx1	2.0 volt
01xx x010	5.0 volt	1001 xxx0	5.0 volt
01xx x011	10 volt	1001 xxx1	10 volt
01xx x111	20 volt	1011 xxx1	20 volt



Note CHANNEL 1 AND 2 MAY NEVER BE ACTIVE SIMULTANEOUSLY. THEREFORE, THE SETTING BYTE MUST ALWAYS BE LESS THAN 192.

Writing to the analogue output

When a value is written on the basic I/O address of the TP5008 (default \$308) a D/A conversion is started at the same time. During the conversion cycle ($< 1 \mu\text{sec}$) the processor will be put in a "wait state". After completing the conversion the processor will continue operating and the D/A convertor output will take on the value written to it. The value has to be written to the D/A convertor in 2's complement, see the following table.

byte to the D/A convertor	output value of the D/A convertor
0111 1111	factor* $\frac{127}{128}$
0000 0001	factor* $\frac{1}{128}$
0000 0000	0 volt
1111 1111	- factor* $\frac{1}{128}$
1000 0001	- factor* $\frac{127}{128}$
1000 0000	- factor* $\frac{128}{128}$

The "factor" value depends on the gain setting of the D/A convertor. The basic output sensitivity of the D/A convertor is 1.25 volt (2.5 volt peak to peak). The amplification can be set through the basic I/O address+1 (default \$309).

input value I/O address \$309	factor value for D/A convertor
0000 0000	1.25 volt
0000 0001	2.5 volt

Chapter 11

Programming the TP5008

Example 1

This example demonstrates sending data to the TP5008, in Turbo Pascal.

```
program SendData;

var byData : array [0..99] of byte;
    index,
    nFreq,
    nAmp   : integer;

begin
  nFreq := 5;           {set frequency}
  nAmp  := 100;        {set amplitude}
  port[$309] := 0;     {set sensitivity}
  for index := 0 to 99 do
  begin                {fill data array}
    byData[index] := round(nAmp* sin(2*pi*nFreq*index/100));
  end;
  for index := 0 to 99 do
  begin
    port[$308] := byData[index];      {send data}
  end;
end.
```

With the instruction `port[$309]` the sensitivity of the D/A convertor is set (the value 0 is a sensitivity of 10 mvolt per bit, while the value 1 is a sensitivity of 20 mvolt per bit).

With the instruction `port[$308]` the data are written to I/O address \$308. The data to address \$308 must be supplied in 2's complement.

Example 2

This example demonstrates reading data from the TP5008, in Turbo Pascal.

```
program ReadData;

var byValue : array[0..99] of byte;
    index   : integer;

begin
  port[$309] := 64;           {select channel 1, 0.5 volt}
  for index := 0 to 99 do
  begin
    byVvalue[index] := port[$308];      {read 100 values}
  end;
  port[$309] := 0;           {turn off channel 1}
  for index := 0 to 99 do
  begin
    writeln(byValue[index]:8);
  end;
end.
```

With the instruction `port[$309] := 64` channel 1 is activated with a sensitivity of 0.5 V full scale. By programming `port[$309] := 128` instead of the above instruction channel 2 will be activated with a sensitivity of 0.5 volt full scale. With the instruction `port[$308]` the values of the A/D convertor are read (the values are in 2's complement)



Note Channels 1 and 2 may never be active simultaneously. Therefore, never assign `port[$309] := 192` or any higher value.

Chapter 12

Specifications

Hardware

A/D convertor

sampling frequency				500 kHz
conversion time				2 μ sec
input sensitivity (for CH 1 and 2)				
	500 mV	(resolution	4	mV)
	1 V	(resolution	8	mV)
	2 V	(resolution	16	mV)
	5 V	(resolution	39	mV)
	10 V	(resolution	78	mV)
	20 V	(resolution	156	mV)
maximum overload voltage				200 V AC 50 Hz
maximum overload voltage 1:10 probe				2000 V AC 50 Hz
input impedance				> 1 M Ω /25 pF
coupling				AC/DC/GND
resolution				8 bits 0.4 %
accuracy				2 % \pm 4 LSB
bandwidth				DC to 100 kHz

D/A convertor

sampling frequency				1000 kHz
conversion time				1 μ sec
output sensitivity	2.5 V	(resolution	20	mV)
	5 V	(resolution	40	mV)
output impedance				50 Ω
coupling				DC
resolution				8 bits 0.4 %
accuracy				1 % \pm 4 LSB
bandwidth				DC to 200 kHz

General

reccomended ambient temperature	20 °C
dimensions	height 3.9 inch / 100 mm length 4.9 inch / 125 mm width 1.0 inch / 25 mm
weigth	approx. 110 gram

Software

Spectrum analyzer

frequency range	0.05 - 24 Hz (resolution 0.05 Hz)
	0.1 - 48 Hz (resolution 0.1 Hz)
	0.25 - 120 Hz (resolution 0.25 Hz)
	0.5 - 240 Hz (resolution 0.5 Hz)
	1.0 - 480 Hz (resolution 1.0 Hz)
	2.5 - 1200 Hz (resolution 2.5 Hz)
	5.0 - 2400 Hz (resolution 5.0 Hz)
	10.0 - 4800 Hz (resolution 10.0 Hz)
	25.0 - 12000 Hz (resolution 25.0 Hz)
	50.0 - 24000 Hz (resolution 50.0 Hz)
<i>(maybe not at a PC-XT)</i>	100.0 - 48000 Hz (resolution 100.0 Hz)
<i>(not at a PC-XT)</i>	166.0 - 80000 Hz (resolution 166.0 Hz)
frequency-axis magnification	2 ... 20 times
y-axis	linear/dB
windows	rectangle window Hanning window Hamming window Blackman window Bartlett window
distortion	measuring 10 harmonics of the ground frequency
hardcopy	matrix and laser printer

Oscilloscope

time base	<i>(not at a PC-XT)</i>	0.2 msec/div
	<i>(maybe not at a PC-XT)</i>	0.5 msec/div
		1.0 msec/div
		2.0 msec/div
		5.0 msec/div
		0.01 sec/div
		0.02 sec/div
		0.05 sec/div
		0.10 sec/div
		0.20 sec/div
		0.50 sec/div
		1.00 sec/div
accuracy of time base		5 %
time-axis magnification		2..20 times
setting accuracy time-axis magnification		0.25 %
y-axis magnification		-5..5 times
triggering	CH1, CH2, positive slope, negative slope	
trigger sensitivity		0.25..2.25 DIV
trigger resolution		0.01 times full scale
trigger time-out		0..50 DIV
external triggering		keyboard
offset setting	CH1 and CH2 separately	
offset range		0..100 %
offset resolution		0.01 times full scale
invert	CH1 and CH2 separately	
add		CH1 + CH2
compare		CH1 relative to CH2
xy-mode	CH1 = x-axis, CH2 = y-axis	
hardcopy		matrix and laser printer

True RMS voltmeter

measuring method	true RMS, mean, min, max, momentary, dBm, power, crest factor and frequency values
display abilities:	CH1, CH2, CH1*CH2, CH1/CH2, CH2/CH1, CH1-CH2, CH2-CH1, CH1+CH2, > then, < then, >< COMP, <>HI LO, MAX, MIN, LOG (CH1/CH2) and LOG (CH2/CH1)
display height	$\pm 1..2$ inch ($\pm 25..50$ mm) depending on the monitor
frequency range	10 Hz, 50 Hz, 100 Hz, 500 Hz, 1 kHz, 5 kHz, 10 kHz
voltage range	500 mvolt (resolution 4 mvolt) 1 volt (resolution 8 mvolt) 2 volt (resolution 16 mvolt) 5 volt (resolution 39 mvolt) 10 volt (resolution 78 mvolt) 20 volt (resolution 156 mvolt)
maximum overload voltage	200 volt peak to peak
maximum overload voltage 1:10 probe	2000 volt peak to peak
data acquire	to disk and to printer

Transient recorder

measuring time between two measuring points	0.01..300 sec at a PC-XT the minimum time is 0.05 sec
maximum number of measuring points to be taken	30,000
time-axis magnification	2..20 times
gain factor	-5..5 times
offset factor	-10,000..10,000
measuring method	true RMS, mean, min, max and momentary
hardcopy	matrix and laser printer

If you have any suggestions and/or remarks regarding the program, the TP5008 or the manual, please contact:

✉ **TiePie engineering**
P.O. Box 290
8600 AG SNEEK
The Netherlands

🏠 **TiePie engineering**
Koperslagersstraat 37
8601 WL SNEEK
The Netherlands
Tel.: +31 515 415 416
Fax: +31 515 418 819