


Programmer's Manual

TiePie Dll's



for: TP112
TP208
TP508
TP801 AWG ISA
TP801 AWG PCI
TE6100
TiePieSCOPE HS508
TiePieSCOPE HS801 AWG
Handyprobe HP2
Handyscope 2
Handyscope 3 AWG

Revision 1.10

Table of contents

Table of contents	1
How can I...	5
Perform my first measurement	5
Understand the error codes	6
Error codes	6
Open / Close the instrument	7
Search and Initialize the Instrument	7
Close the Instrument	7
Get information about my instrument	8
Get the calibration date	8
Get the instrument serial number	8
Determine the available input sensitivities	9
Determine the available input resolutions	9
Get the maximum sampling frequency	10
Get the maximum record length	10
Check for availability of DC hardware offset adjustment	10
Check for a square wave generator	11
Check for a function generator	11
Get the maximum amplitude of the function generator	11
Perform a measurement	12
Start the measurement	12
Retrieve the data	13
Get all measurement data in Volts	13
Get one sample of the measurement data, in Volts	13
Get all measurement data, binary	14
Get one sample of the measurement data, binary	14
Get all digital input values	15
Get one sample of the digital input values	15
Advanced measurement routines	16
Start a measurement	16
Check if the hardware is measuring	16
Abort a running measurement	17
Read the trigger status	17
Read the measurement status	18
Retrieve the measured data	18

Example of use of the routines	19
Controlling the input resolution	20
Set the input resolution	20
Get the current input resolution	20
Control which channels are measured	21
Get the current measure mode	21
Set the measure mode	21
Control the time base	22
Get the current record length	22
Set the record length	22
Get the current number of post samples	23
Set the number of post samples	23
Get the current sampling frequency	24
Set the sampling frequency	24
Get the sample clock status	25
Set the sample clock status	25
Control the analog input channels	26
Get the current input sensitivity	26
Set the input sensitivity	26
Get the current auto ranging status	27
Set the auto ranging status	27
Get the current input coupling	28
Set the input coupling	28
Get the current DC level value	29
Set the DC level value	29
Control the trigger system	30
Get the current trigger source	30
Set the trigger source	30
Get the current trigger mode	31
Set the trigger mode	31
Get the current trigger level	32
Set the trigger level	32
Get the current trigger hysteresis	33
Set the trigger hysteresis	33
Select the PXI external trigger signals	34
Get the current used PXI external trigger signals	34
Set the PXI external trigger slopes	35
Get the current PXI external trigger slopes	35
Get the current trigger timeout value	36
Set the trigger timeout value	36

Control the digital outputs	37
Set the digital outputs	37
Get the current status of the digital outputs	37
Control the Square Wave generator	38
Get the current square wave generator frequency	38
Set the square wave generator frequency	38
Control the Arbitrary Waveform Generator	39
Set the generator signal type	39
Get the current generator signal type	39
Set the generator amplitude	40
Get the current generator amplitude	40
Set the generator DC Offset	41
Get the current generator DC Offset	41
Set the generator signal symmetry	42
Get the current generator signal symmetry	42
Set the generator frequency	43
Get the current generator frequency	44
Fill the function generator waveform memory	45
Set the generator output state	46
Get the current generator output state	46

Perform my first measurement

Before performing a measurement, the instrument must first be initialized, using the routine `InitInstrument`. If this routine returns a non-zero value the initialization has failed and it is not possible to perform any measurements.

After initializing the hardware you can:

- modify the measurement settings
- start a measurement

These two actions can be executed in any order and as often as required.

Finally the routine `ExitInstrument` has to be called to deactivate the instrument and free any used resources.

Example in Pascal code:

```
const E_NO_ERRORS = 0;

if InitInstrument = E_NO_ERRORS then      {initialize instrument}
begin                                    {and allocate resources}
    while MeasureMore do
    begin
        if ChangeSettings then
        begin
            OldFreq := GetFrequency;      {query a setting}
            SetFrequency((OldFreq* 10)-1000 ); {change a setting}
        end; { if }
        if StartMeasurement = E_NO_ERRORS then {measure}
        begin
            for Sample := 0 to GetRecordLengh do
            begin                            {retrieve data}
                GetOneMeasurement(Data1[Sample], Data2[Sample]);
            end; { for }
        end; { if }
    end; { while }
    ExitInstrument;                          { free resources}
end
else
begin
    writeln( 'Error: No hardware found...' );
end; { else }
```


Legend:

bold = reserved words
123 = number
italic = comment

Understand the error codes

Error codes

Code Names

Code Values

	Hexadecimal	Binary
E_INVALID_VALUE	= 0x0020 ;	/*0000000000100000*/
E_INVALID_CHANNEL	= 0x0010 ;	/*0000000000010000*/
E_NO_GENERATOR	= 0x0008 ;	/*0000000000001000*/
E_NOT_SUPPORTED	= 0x0004 ;	/*0000000000000100*/
E_NOT_INITIALIZED	= 0x0002 ;	/*0000000000000010*/
E_NO_HARDWARE	= 0x0001 ;	/*0000000000000001*/
E_NO_ERRORS	= 0x0000 ;	/*0000000000000000*/

Search and Initialize the Instrument

`word InitInstrument (word wAddress);`

Descriptions: Initialize the hardware of the instrument. Set default measurement settings, allocate memory and obtain the calibration constants etc.

Parallel port connected instruments, USB instruments and PCI bus instruments detect the hardware by themselves and ignore the address parameters.

Input: **wAddress** The hardware address of the instrument should be passed to this routine.

Output: **Returnvalue** E_NO_ERRORS;
 E_NO_HARDWARE

Note All instruments have their calibration constants in internal, non-volatile memory, except for the TP208 and TP508. These have to be calibrated using internal routines. This is done automatically at first startup everyday. Some relays will begin to click.

Close the Instrument

`word ExitInstrument (void);`

Description: Close the instrument. Free any allocated resources and memory, place the relays in their passive state, etc.

Input: -

Output: **Returnvalue** E_NO_ERRORS;
 E_NOT_INITIALIZED

Get information about my instrument

Get the calibration date

word GetCalibrationDate (dword *dwDate);

Description: This routine returns the calibration date of the instrument.
The date is encoded in a packed 32 bit variable:

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
|<----->|<----->|<----->|<----->|
|   day (8 bits)   | (month (8 bits)   |   year (16 bits)   |
```

Example decoding routine in C/C++:

```
day   = number >> 24;           /* highest 8 bits */
month = (number >> 16) & 0xFF;  /* middle 8 bits */
year  = number & 0xFFFF;       /* lowest 16 bits */
```

Input: -

Output: dwDate The calibration date

Returnvalue E_NO_ERRORS

E_NOT_SUPPORTED

Get the instrument serial number

word GetSerialNumber (dword *dwSerialNumber);

Description: This routine returns the Serial Number of the instrument.
This number is hardcoded in the hardware. TP112, TP208
and TP508 do not have a serial number in the instrument.

Input: -

Output: dwSerialNumber the serial number

Returnvalue E_NO_ERRORS

E_NOT_SUPPORTED

Determine the available input sensitivities

word GetAvailableSensitivities(double *dSensitivities);

description: This routine retrieves the available input sensitivities from the hardware and stores them in an array.

dSensitivities is an 20 elements large array. The caller must ensure that there is enough space in the arrays to contain the data. Therefor both the arrays must be at least

20 * sizeof(double)

At return, all elements containing a non-zero value, contain an input sensitivity. This is a full scale value. So if an element contains the value 4.0, the input sensitivity is 4 Volt full scale, enabling to measure input signals from -4 Volt - + 4 Volt.

input:

-

output:

dSensitivities Return address for the array of input sensitivities

Returnvalue E_NO_ERRORS

Determine the available input resolutions

word GetAvailableResolutions(double *dResolutions);

description: The Handyscope 3 supports different, user selectable input resolutions. This routine retrieves the available input resolutions from the hardware and stores them in an array.

dResolutions is an 20 elements large array. The caller must ensure that there is enough space in the arrays to contain the data. Therefor both the arrays must be at least

20 * sizeof(double)

At return, all elements containing a non-zero value, contain an input resolution in number of bits.

input:

-

output:

dResolutions Return address for the array of input sensitivities

Returnvalue E_NO_ERRORS

Get the maximum sampling frequency

dword GetMaxSampleFrequency(void);

Description: The different instruments have different maximum sampling frequencies. This routine queries the maximum sampling frequency.

Input: -

Output: **Returnvalue** The maximum sampling frequency the instrument supports in Hz.

Get the maximum record length

dword GetMaxRecordLength(void);

Description: The different instruments have different record lengths. This routine queries the maximum available record length per channel, in samples.

Input: -

Output: **Returnvalue** The maximum record length the instrument supports in number of samples.

Check for availability of DC hardware offset adjustment

word GetDCLevelStatus(void);

Description: Some instruments support DC Hardware offset adjustment. This routine checks if the DC Level is supported.

Input: -

Output: **Returnvalue** E_NO_ERRORS
E_NOT_SUPPORTED

Check for a square wave generator

word GetSquareWaveGenStatus(void);

Description: Some instruments have a built-in square wave generator, the HS508 for example. This routine checks the presence of the generator.

Input:

-

Output:

Returnvalue E_NO_ERRORS
E_NO_GENERATOR

Check for a function generator

word GetFunctionGenStatus(void);

Description: The TiePieSCOPE HS801, TP801 and Handyscope 3 can have a built-in arbitrary waveform generator. When this function returns E_NO_GENERATOR, the HS801, TP801 or Handyscope 3 is equipped with a simple square wave generator.

Input:

-

Output:

Returnvalue E_NO_ERRORS
E_NO_GENERATOR

Get the maximum amplitude of the function generator

word GetFuncGenMaxAmplitude(double *dAmplitude);

Description: The maximum output voltage for the TiePieSCOPE HS801 and Handyscope 3 generator is 12 Volt, the maximum output voltage for the TP801 generator is 10 Volt. This routine determines the maximum voltage.

Input:

-

Output:

dAmplitude The maximum amplitude the generator supports.
Returnvalue E_NO_ERRORS
E_NO_GENERATOR

Start the measurement

word StartMeasurement (void);

Description: This routine tells the hardware to perform a single measurement. The measurement is initiated, and then the routine will wait until the hardware is ready. When the hardware is ready, the measured data is transferred from the hardware acquisition memory into the computer memory, inside the DLL.

Input: -

Output: Returnvalue E_NO_ERRORS
E_NOT_INITIALIZED

Remark: Perform a measurement. One (software) measurement equals a `record_length` number of hardware-measurements. So the hardware will fill it's internal buffer. This routine will wait until the hardware is done.

Get all measurement data in Volts

`word GetMeasurement (double *dCh1, double *dCh2);`

Description: This routine transfers the measured data from the acquisition memory in the DLL into the memory in the application. For each sample, the value in Volts is calculated.

dCh1 and dCh2 are both array. The caller must ensure that there is enough space in the arrays to contain the data. Therefore both the arrays must be at least

`RecordLength * sizeof(double)`

Input:

-

Output:

dCh1 The array to which the data of channel 1 should be passed.

dCh2 The array to which the data of channel 2 should be passed.

Returnvalue `E_NO_ERRORS`

Get one sample of the measurement data, in Volts

`word GetOneMeasurement (dword wIndex, double *dCh1, double *dCh2);`

Description: This routine transfers a single sample per channel from the acquisition memory in the DLL into the memory of the application. The value in Volts is calculated for each sample.

Input: **wIndex** The index of the measured data point.

Output: **dCh1** Return address for the measured data from channel 1.

dCh2 Return address for the measured data from channel 2.

Returnvalue `E_NO_ERRORS`

Get all measurement data, binary

word GetMeasurementRaw (word *wCh1, word *wCh2);

Description: This routine transfers the measured data from the acquisition memory in the DLL into the memory in the application. The measured data is returned in binary values. A value of 0 corresponds to -Sensitivity, 32767 corresponds to 0 and 65535 to +Sensitivity in Volts. wCh1 and wCh2 are arrays. The caller must ensure that there is enough space in the arrays to contain the data. Therefore the arrays must be at least
RecordLength * sizeof(word)

Input:

-

Output:

wCh1 The array to which the measured data of channel 1 should be passed.

wCh2 The array to which the measured data of channel 2 should be passed.

Returnvalue E_NO_ERRORS

Get one sample of the measurement data, binary

word GetOneMeasurementRaw(dword wIndex, word *wCh1, word *wCh2);

Description: This routine transfers a single sample per channel from the acquisition memory in the DLL to the memory of the application. The measured data is returned in binary values. A value of 0 corresponds to -Sensitivity, 32767 corresponds to 0 and 65535 to +Sensitivity in Volts.

Input:

wIndex The index of the measured data point

Output:

wCh1 Return address for the measured data from channel 1

wCh2 Return address for the measured data from channel 2

Returnvalue E_NO_ERRORS

Get all digital input values

word GetDigitalInputValues(word *wValues);

Description: The TP112 has eight digital inputs, which are sampled simultaneously with the analog input channels.

This routine transfers the measured digital values from the memory in the DLL into the memory in the application. The measured data is returned in binary values. Each bit in the digital data words represents a digital input. wValues is an array. The caller must ensure that there is enough space in the array to contain the data. Therefore the array must be at least

RecordLength * sizeof(word)

Input:

-

Output:

Returnvalue E_NO_ERRORS
E_NOT_SUPPORTED

Get one sample of the digital input values

word GetOneDigitalValue(word wIndex; word *wValue);

Description: This routine transfers a single digital input value from the memory in the DLL to the memory of the application.

Input:

wIndex The index of the measured data point, relative to the trigger point (negative for pre samples, positive for post samples)

Output:

wValue Return address for the digital input value.
Returnvalue E_NO_ERRORS
E_NOT_SUPPORTED

Advanced measurement routines

The previously mentioned routine `StartMeasurement` takes care of a complete measurement. It sets up the hardware to perform a measurement and then starts the hardware measurement. Then it will wait for the measurement to be ready. In the mean while, it checks the triggered flag of the hardware and checks if a trigger time out has occurred. If that has happened, it will force a trigger. Then it will wait for the measurement to be ready. When the measurement is ready, the measured data will be transferred from the hardware to memory inside the DLL. While doing that, it will check if auto range is required. When all data is transferred and checked, the routine will end.

The application can then transfer the data from the DLL memory to it's own memory and process it.

For certain applications it might be usefull to split up this process into individual steps. The following routines enable this. When these routines are used, no Trigger timeout is available.

Start a measurement

`word ADC_Start;`

Description: This routine writes any new instrument setting information to the hardware and then starts the measurement. If the hardware is already measuring, this measurement is aborted. Previous measured data is lost

Input: -

Output: Returnvalue `E_NOT_INITIALIZED`
 `E_NO_ERRORS`

Check if the hardware is measuring

`word ADC_Running;`

Description: This routine checks if the hardware is currently measuring

Input: -

Output: Returnvalue 0 = not measuring
 1 = measuring

Abort a running measurement

word ADC_Abort;

Description: This routine aborts a running measurement. Any measured data is lost. It is not required to abort a running measurement before starting a new one, StartMeasurement does this already.

Input: -

Output: Returnvalue E_NOT_INITIALIZED
 E_NO_ERRORS

Read the trigger status

word ADC_Triggered;

Description: This routine reads the trigger status from the hardware.

Input: -

Output: Returnvalue 0 = not triggered
 1 = Ch1 caused trigger
 2 = Ch2 caused trigger
 4 = External input caused trigger

Remark: Returnvalue can be a combination of indicated values.

Read the measurement status

word ADC_Ready;

Description: This routine checks if the measurement is ready or not.

Input: -

Output: Returnvalue 0 = not ready
 1 = ready

Retrieve the measured data

word ADC_GetData (word *wCh1, word *wCh2);

Description: This routine transfers the measured data from the acquisition memory in the hardware via the dll into the memory in the application. The measured data is returned in binary values. A value of 0 corresponds to -Sensitivity, 32767 corresponds to 0 and 65535 to +Sensitivity in Volts. wCh1 and wCh2 are arrays. The caller must ensure that there is enough space in the arrays to contain the data. Therefor the arrays must be at least

RecordLength * sizeof(word)

Input: -

Output: wCh1 The array to which the measured data of channel 1 should be passed.
 wCh2 The array to which the measured data of channel 2 should be passed.
 Returnvalue E_NO_ERRORS

Example of use of the routines

To use the advanced measurement routines, your application could look like the following:

```
.  
.   
ADC_Start;  
while bContinue do  
begin  
    if ADC_Ready = 1 then  
        begin  
            ADC_Getdata( @Ch1WordArray, @Ch2WordArray );  
            ADC_Start;  
            ApplicationProcessData;  
end; { if }  
.   
.
```

Controlling the input resolution

The Handyscope 3 supports a number of different input resolutions.

Set the input resolution

word SetResolution(byte byResolution);

Description: This routine sets the input resolution of the hardware.
Use `GetAvailableResolutions()` to determine which resolutions are available.

Input: **byResolution** the new resolution, in bits

Output: **Returnvalue** E_NO_ERRORS
E_INVALID_VALUE
E_NOT_SUPPORTED

Remark: When setting a new input resolution, the maximum sampling frequency of the hardware changes as well.
Use `GetMaxSampleFrequency()` to determine the new maximum sampling frequency.

Get the current input resolution

word GetResolution (byte *byResolution);

Description: This routine retrieves the currently set input resolution in bits.

Input: -

Output: **byResolution** the return address for the resolution
Returnvalue E_NO_ERRORS

Get the current measure mode

word GetMeasureMode(byte *byMode);

Description: This routine returns the current Measure Mode:

- 1 : Ch1 the signal at channel 1 is measured
- 2 : Ch2 the signal at channel 2 is measured
- 3 : Ch1 & Ch2 the signals at channel 1 and 2 are measured simultaneously

Input: -

Output: byMode The return address for the Measure Mode.

Returnvalue E_NO_ERRORS
 E_INVALID_VALUE

Set the measure mode

word SetMeasureMode(byte byMode);

Description: This routine changes the Measure Mode, see also **GetMeasureMode**.

Input: byMode The new measure mode (1, 2 or 3).

Output: Returnvalue E_NO_ERRORS
 E_INVALID_VALUE

Get the current record length

`dword GetRecordLength(void);`

Description: This routine returns the total number of points to be digitized. The number of pre samples (number of samples to measure **before** the trigger occurred) is calculated like this:
`PreSamples = RecordLength - PostSamples.`

Input: -

Output: **Returnvalue** The total number of points to be digitized per channel.

Set the record length

`word SetRecordLength(dword wTotal);`

Description: This routine sets the total number of points to be digitized. The maximum record length can be determined with the routine `GetMaxRecordLength()`. The minimum is 0.

Input: **wTotal** The total number of points to be digitized per channel.

Output: **Returnvalue** E_NO_ERRORS
E_INVALID_VALUE

Remark: Setting a record length smaller than the number of post samples gives an E_INVALID_VALUE error

Get the current number of post samples

dword GetPostSamples(void);

Description: This routine returns the number of post samples to measure (the number of samples **after** the trigger has occurred).

Input: -

Output: **Returnvalue** The current selected number of post samples to measure.

Set the number of post samples

word SetPostSamples(dword wPost);

Description: This routine sets the number of post samples. This number must be between 0 and the record length.

Input: **wPost** The requested number of post samples to measure.

Output: **Returnvalue** E_NO_ERRORS
 E_INVALID_VALUE

Remark: Setting a number of post samples larger than the record length gives an E_INVALID_VALUE error

Get the current sampling frequency

dword GetSampleFrequency(void);

Description: This routine returns the current set sampling frequency in Hz. The minimum/maximum frequency supported is instrument dependent.

Input: -

Output: **Returnvalue** The current sampling frequency in Hz.

Set the sampling frequency

word SetSampleFrequency(dword *dFreq);

Remarks: The routine sets the sampling frequency. The hardware is not capable of creating every selected frequency so the hardware chooses the nearest allowed frequency to use, this is the frequency that is returned in dFreq.

Input: **dFreq** The requested sampling frequency in Hz

Output: **dFreq** The actual selected sampling frequency in Hz.

Returnvalue E_NO_ERRORS

Get the sample clock status

word GetExternalClock(word *wMode);

Description: This routine determines whether the sampling clock uses the internal Crystal oscillator or the external clock input
Only 50 MHz devices support external clock input

Input:

-

Output:

wMode The status of the internal clock,
 0 = clock internal
 1 = clock external

Returnvalue E_NO_ERRORS
 E_NOT_SUPPORTED

Set the sample clock status

word SetExternalClock(word wMode);

Description: This routine sets the sampling clock mode: is te internal crystal oscillator used or the external clock input?
Only 50 MHz devices support external clock input

Input:

wMode 0 = internal clock
 1 = external clock

Output:

Returnvalue E_NO_ERRORS
 E_INVALID_VALUE
 E_NOT_SUPPORTED

Get the current input sensitivity

word GetSensitivity (byte byCh, double *dSens);

Description: This routine returns the current selected full scale input sensitivity in Volts for the selected channel.

Input: byCh The channel whose current Sensitivity is requested (1, 2)

Output: dSens The return address for the sensitivity.

Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL

Set the input sensitivity

word SetSensitivity(byte byCh, double *dSens);

Description: This routine sets the Sensitivity for the selected channel. The hardware can only deal with a limited number of ranges. The sensitivity that matches the entered sensitivity best is used. This is the value that will be returned in dSens.

Input: byCh The channel whose Sensitivity is to be changed (1, 2)

 dSens The new Sensitivity in Volts

Output: dSens Contains the actual set Sensitivity, on return

Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL

Get the current auto ranging status

word GetAutoRanging(byte byCh, byte *byMode);

Description: This routine returns the current autoranging mode:

0 : autoranging is off

1 : autoranging is on.

If autoranging is on then for a channel the sensitivity will be automatically adjusted if the input signal becomes too large or too small.

When a measurement is performed, the data is examined. If that data indicates another range will provide better results, the hardware is set to a new sensitivity. The **next** measurement that is performed, will be using that new sensitivity. Autoranging has no effect on a current measurement.

Input: byCh The channel whose current Autoranging mode is requested (1, 2).

Output: byMode Return address for the Autoranging mode.

Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL

Set the auto ranging status

word SetAutoRanging(byte byCh, byte byMode);

Description: This routine selects the autoranging mode:

0 : turn Autoranging off

1 : turn Autoranging on.

See also **GetAutoRanging**.

Input: byCh The channel whose Autoranging mode has to be set (1, 2).

byMode The new value for the Autoranging mode.

Output: Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL
 E_INVALID_VALUE

Get the current input coupling

word GetCoupling(byte byCh, byte *byMode);

Description: This routine returns the current signal coupling for the selected channel:

0 : coupling AC

1 : coupling DC.

In DC mode both the DC and the AC components of the signal are measured.

In AC mode only the AC component is measured.

Input: **byCh** The channel whose current coupling is requested (1, 2)

Output: **byMode** Return address for the current coupling.

Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL
 E_INVALID_VALUE

Set the input coupling

word SetCoupling(byte byCh, byte byMode);

Description: This routine changes the signal coupling for the selected channel. See also **GetCoupling**.

Input: **byCh** The channel whose Coupling is to be changed (1, 2).

byMode The new coupling for the selected channel (0 or 1).

Output: **Returnvalue** E_NO_ERRORS
 E_INVALID_CHANNEL
 E_INVALID_VALUE

Get the current DC level value

word GetDcLevel(byte byCh, double *dLevel);

Description: This routine returns the current DC Level value for the selected channel. This voltage is added to the input signal before digitizing. This is used to shift a signal that is outside the current input range into the input range.

Input: **byCh** The channel whose DC Level is requested (1, 2)

Output: **dLevel** Return address for the current DC Level.

Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL
 E_NOT_SUPPORTED

Set the DC level value

word SetDcLevel(byte byCh, double dLevel);

Description: This routine is used to change the DC Level for the selected channel. The DC Level has a minimum of $-2 \times \text{sensitivity}$ and a maximum of $+2 \times \text{sensitivity}$. If the sensitivity changes, the DC level is automatically checked and clipped if necessary. See also GetDcLevel.

Input: **byCh** The channel whose DC Level is to be set (1, 2)

dLevel The new DC Level in Volts

Output: **Returnvalue** E_NO_ERRORS
 E_INVALID_CHANNEL
 E_INVALID_VALUE
 E_NOT_SUPPORTED

Get the current trigger source

word GetTriggerSource(byte *bySource);

Description: This routine is used to retrieve the current Trigger Source. The hardware waits for a trigger condition, or a Timeout, before it starts to measure.

0	:	Ch1Trig	Channel 1
1	:	Ch2Trig	Channel 2
2	:	ExtTrig	a digital external signal
3	:	AndTrig	Channel 1 AND Channel 2
4	:	OrTrig	Channel 1 OR Channel 2
5	:	NoTrig	no source, measure immediately
6	:	PxiExtTrig	PXI bus digital trigger signals
7	:	XorTrig	Channel 1 XOR Channel 2
8	:	AnaExtTrig	an analog external signal

Input: -

Output: bySource The current trigger source.

Returnvalue E_NO_ERRORS
E_INVALID_VALUE

Set the trigger source

word SetTriggerSource(byte bySource);

Description: This routine sets the trigger source, see GetTriggerSource for the codes of the different sources.

Input: bySource The new trigger source.

Output: Returnvalue E_NO_ERRORS
E_INVALID_VALUE
E_NOT_SUPPORTED

Note Not all instruments support all Trigger Sources. Look at the manual of your instrument for details, which Trigger Sources your instrument supports. If the Trigger Source is not supported, the error value **E_NOT_SUPPORTED** is returned.

Get the current trigger mode

word GetTriggerMode(byte *byMode);

Description: This routine is used to query the current Trigger Mode.

0	Rising	trigger on rising slope
1	Falling	trigger on falling slope
2	InWindow	trigger when signal gets inside window
3	OutWindow	trigger when signal gets outside window
4	TVLine	trigger on TV line sync pulse
5	TVFieldOdd	trigger on TV odd frame sync pulse
6	TVFieldEven	trigger on TV even frame sync pulse

Input:

-

Output: byMode The current trigger mode.

Returnvalue E_NO_ERRORS
E_INVALID_VALUE

Set the trigger mode

word SetTriggerMode(byte byMode);

Description: This routine is used to set the Trigger Mode. See also **GetTriggerSource**. Some trigger modes are not available on all instruments, in that case, the value E_NOT_SUPPORTED will be returned.

Input: byMode The new trigger mode.

Output: Returnvalue E_NO_ERRORS
E_INVALID_VALUE
E_NOT_SUPPORTED

Get the current trigger level

word GetTriggerLevel(byte byCh, double *dLevel);

Description: This routine is used to retrieve the Trigger Level of the selected channel. The hardware starts to measure when the signal passes this level. The routine SetTriggerMode can be used to select the trigger slope.

Input: byCh The channel whose Trigger Level is to be retrieved (1 or 2).

Output: dLevel Return address for the Trigger Level.

Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL

Set the trigger level

word SetTriggerLevel(byte byCh, double dLevel);

Description: This routine is used to set the Trigger Level. The Trigger Level is valid if it is between -sensitivity and +sensitivity.

Input: byCh The channel whose Trigger Level is to be set (1 or 2).

 dLevel The new Trigger Level in Volts.

Output: Returnvalue E_NO_ERRORS
 E_INVALID_CHANNEL
 E_INVALID_VALUE

Note The Trigger Level applies only to analog trigger sources, not to digital trigger sources.

Get the current trigger hysteresis

word GetTriggerHys(byte byCh; double *dHysteresis);

Description: This routine is used to retrieve the current Trigger Hysteresis. The hysteresis is the minimum voltage change that is required to comply with the trigger conditions. This is used to minimize the influence of the noise on a signal on the trigger system.

Input: **byCh** The channel whose Trigger Hysteresis is to be retrieved (1 or 2).

Output: **dHysteresis** Return address for the Trigger Hysteresis.
 Returnvalue E_NO_ERROR
 E_INVALID_CHANNEL

Set the trigger hysteresis

word SetTriggerHys(byte byCh; double dHysteresis);

Description: This routine changes the hysteresis, see also GetTriggerHys.

Input: **byCh** The channel whose Trigger Hysteresis is to be set (1 or 2).

dHysteresis The new trigger hysteresis.
Output: **Returnvalue** E_NO_ERRORS
 E_INVALID_VALUE
 E_INVALID_CHANNEL

Upper and lower limits of the hysteresis:

Slope	Lower limit	Upper limit
rising	0	level + sens
falling	0	sens - level

Note The Trigger Hysteresis applies only to analog trigger sources, not to digital trigger sources.

The TE6100 has 8 digital external trigger inputs, at the PXI bus, which can be used to trigger the measurement. It is possible to select which inputs have to be used and if the inputs have to respond to a rising or a falling slope.

Select the PXI external trigger signals

```
word SetPXITriggerEnables( byte byEnables );
```

Description: This routine determines which of the eight PXI external trigger inputs have to be used. When more than one input is selected, trigger occurs when one or more inputs become active (logic OR). Which input state is active, is determined by the Slopes setting, see next page.

Input: **byEnables** a bit pattern that defines which inputs have to be used. Bit 0 represents input 0, bit 1 represents input 1 etc.
When a bit is high, the corresponding input is used.
When a bit is low, the corresponding input is not used.

Output: **Returnvalue** E_NO_ERRORS,
E_NOT_SUPPORTED

Get the current used PXI external trigger signals

```
word GetPXITriggerEnables( byte *byEnables );
```

Description: This routine retrieves the currently selected PXI external trigger inputs.

Input: -

Output: **byEnables** a bit pattern that defines which inputs are currently used. See also the routine SetPXITriggerEnables

Returnvalue: E_NO_ERRORS
E_NOT_SUPPORTED

Set the PXI external trigger slopes

word SetPXITriggerSlopes(byte bySlopes);

Description: This routine determines for each PXI external trigger input individually whether it should respond to a falling or a rising slope.

Input: **bySlopes** a bit pattern that defines how the slope settings for each input is set.
Each bit represents an input, bit 0 represents input 0, bit 1 represents input 1 etc.
When a bit is high, the corresponding input responds to a rising slope.
When a bit is low, the corresponding input responds to a falling slope.

Output: **ReturnValue** E_NO_ERRORS
E_NOT_SUPPORTED

Get the current PXI external trigger slopes

word GetPXITriggerSlopes(byte *bySlopes);

Description: This routines determines how the slope sensitivities for the PXI external trigger inputs are set.

Input: -

Output: **bySlopes** a bit pattern that defines how the slope settings for each input is set.
Each bit represents an input, bit 0 represents input 0, bit 1 represents input 1 etc.
When a bit is high, the corresponding input responds to a rising slope.
When a bit is low, the corresponding input responds to a falling slope.

Returnvalue E_NO_ERRORS
E_NOT_SUPPORTED

Get the current trigger timeout value

`dword GetTriggerTimeOut(void);`

Description: This routine is used to query the current Timeout value. When this Timeout period has elapsed and the hardware has not seen a trigger, then a trigger is forced so that the hardware can start to measure. This way it is possible to measure a signal that has not met the trigger conditions.

Input: -

Output: **Returnvalue** The current Timeout value in msec.

Set the trigger timeout value

`dword SetTriggerTimeOut(dword ITimeout);`

Description: This routine sets the Timeout value, see also `GetTimeOut`.

Input: **ITimeout** The new timeout value in msec.

Output: **Returnvalue** E_NO_ERRORS

Set the digital outputs

```
word SetDigitalOutputs( byte byValue );
```

Description: The TP112 is equipped with 8 digital outputs, which can be set individually.

This routine sets the status of the digital outputs.

Input: **byValue** the new status of the outputs. Each bit represents an output.

Output: **Returnvalue** E_NO_ERRORS
 E_NOT_SUPPORTED

Get the current status of the digital outputs

```
word GetDigitalOutputs( byte *byValue );
```

Description: This routine gets the current status of the digital outputs.

Input: -

Output: **byValue** the status of the outputs. Each bit represents an output.

Returnvalue E_NO_ERRORS
 E_NOT_SUPPORTED

Get the current square wave generator frequency

`double GetSquareWaveGenFrequency(void);`

Description: Some instruments have a built-in generator, the HS508 for example. This routine returns the generator frequency in Hz.

Input: -

Output: **Returnvalue** The generator frequency in Hz.

Remarks: Not all instruments have a square wave generator, use the routine `GetSquareWaveGenStatus()` to check if a square wave generator is available

Set the square wave generator frequency

`word SetSquareWaveGenFrequency(double *dFreq);`

Remarks: The routine sets the frequency. The hardware is not capable of using every frequency so the hardware chooses the nearest legal frequency to use, this is the frequency that is returned in `dFreq`. See also `GetGeneratorFrequency`.

Input: **dFreq** the requested frequency in Hz.

A value "zero" switches the output off

Output: **dFreq** the frequency that is actually made.

Returnvalue `E_NO_ERRORS`

`E_NO_GENERATOR`

Remarks: Not all instruments have a square wave generator, use `GetSquareWaveGenStatus()` to check if a square wave generator is available

Set the generator signal type

word SetFuncGenSignalType(word wSignalType);

Description: This routine sets the signal type of the function generator.

Input: **wSignalType** The requested signal type

- 0 Sine wave
- 1 Triangular wave
- 2 Square wave
- 3 DC
- 4 Noise
- 5 Arbitrary signal

Output: **Returnvalue:** E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Remark: When **Arbitrary** is selected, the contents of the function generator memory will be "played" continuously. This memory is used for every signal type, so each time when selecting **Arbitrary**, use the function **FillFuncGenMemory()** to fill the memory with the requested signal.

Get the current generator signal type

word GetFuncGenSignalType(word *wSignalType);

Description: This routine returns the currently selected signal type.

Input: -

Output: **wSignalType** The currently selected signal type
 See **SetFuncGenSignalType** for possible values for wSignalType

Returnvalue E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Set the generator amplitude

word SetFuncGenAmplitude(double dAmplitude);

Description: This routine sets the output amplitude of the function generator in volts. When the requested amplitude is smaller than zero or larger than the maximum supported amplitude, E_INVALID_VALUE is returned and the requested value is ignored.

When signal type DC is selected, the absolute amplitude of the signal is determined by the amplitude and the polarity is determined through the **DC offset**.

Input: **dAmplitude** the function generator amplitude in Volts:
 0 <= value <= MaxAmplitude

Output: **Returnvalue** E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Get the current generator amplitude

word GetFuncGenAmplitude(double *dAmplitude);

Description: This routine determines the currently selected amplitude of the function generator

Input: -

Output: **dAmplitude** the function generator amplitude in Volts:
 0 <= value <= MaxAmplitude

Returnvalue E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Set the generator DC Offset

```
word SetFuncGenDCOffset( double dDCOffset );
```

Description: This routine applies a DC offset to the output signal. The value is entered in Volts.

When signal type **DC** is selected, the DC offset value is used to determine the polarity of the output signal. A value ≥ 0 Volt results in a positive output signal, a value < 0 Volt results in a negative output signal. The amplitude of the DC signal is determined through the Amplitude value.

Input: dDCOffset the requested offset in Volts:
-MaxAmpl <= value <= +MaxAmpl

```
Output: Returnvalue E_NO_ERRORS
        E_NO_GENERATOR
        E_INVALID_VALUE
```

Get the current generator DC Offset

```
word GetFuncGenDCOffset( double *dDCOffset );
```

Description: This routine determines the currently selected DC offset value of the function generator

Input: -

<i>Output:</i>	dDCOffset	the currently selected DC Offset value
	Returnvalue	E_NO_ERRORS
		E_NO_GENERATOR
		E_INVALID_VALUE

Set the generator signal symmetry

word SetFuncGenSymmetry(double dSymmetry);

Description: This routine sets the symmetry of the output signal. The symmetry can be set between 0 and 100. With a symmetry of 50, the positive part of the output signal and negative part of the output signal are equally long. With a symmetry of 25, the positive part of the output signal takes 25% of the total period and the negative part takes 75% of the total period. With signal types **DC**, **Noise** and **Arbitrary**, the symmetry value is ignored.

Input: **dSymmetry** The requested symmetry value:
 0 <= value <= 100

Output: **Returnvalue** E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Get the current generator signal symmetry

word GetFuncGenSymmetry(double *dSymmetry);

Description: This routine retrieves the currently selected symmetry of the output signal.

Input: -
Output: **dSymmetry** the current symmetry value
 Returnvalue E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Set the generator frequency

word SetFuncGenFrequency(double *dFrequency);

Description: When signal type Sine, Triangular, Square or Noise is selected (DDS mode), this routine sets the frequency of the output signal of the function generator.

When signal type **Arbitrary** is selected, the frequency settings behaves slightly different. When 1024 samples are loaded into the waveform memory (DDS mode), this routine sets the frequency of the output signal. When 65536 samples are loaded into the waveform memory (linear mode), this routine sets the frequency of the sampling clock of the function generator. Only a limited number of frequencies are available.

Input: **dFrequency** DDS mode: the requested frequency of the output signal:

0.001 <= dFrequency <= 2,000,000

Linear mode: the requested frequency of the sampling clock in 15 steps:

38.1,	610,	2441,
9765,	39062,	78125,
156250,	321500,	625000,
1250000,	2500000,	5000000,
10000000,	25000000,	50000000

Output: **dFrequency** the hardware can not support any arbitrary frequency within the available range. The value that was actually selected is returned.

Returnvalue E_NO_ERRORS
E_NO_GENERATOR
E_INVALID_VALUE

Get the current generator frequency

word GetFuncGenFrequency(double *dFrequency);

Description: This routine determines the currently set frequency.

Input: -

Output:

dFrequency	The currently set frequency in Hz
Returnvalue	E_NO_ERRORS
	E_NO_GENERATOR
	E_INVALID_VALUE

Fill the function generator waveform memory

word FillFuncGenMemory(dword wNrPoints; word *wFuncGenData);

description: This routine fills the function generator waveform memory with user defined data.

The generator can operate in two different modes: DDS and Linear. When operating in DDS mode, 1024 samples must be loaded. These 1024 samples will form one period of the output signal. When operating in Linear mode, the maximum record length samples (depends on the instrument, e.g. 65536 or 131072) must be loaded. These samples will form one period of the output signal.

The data must be in unsigned 16 bits values. A value of 32767 produces a 0 Volt signal, 65535 results in positive full output scale and a value of 0 results in negative full output scale.

The amplitude parameter of the function generator determines the exact value of full scale. If an amplitude of 8 Volt is selected, full scale will be 8 Volt.

<i>Input:</i>	dNrPoints	the number of waveform points that must be loaded: 1024 or 65536 or 131072. Also determines whether the function generator operates in DDS or Linear mode.
	wFuncGenData	an array of 65536 or 131072 unsigned 16 bits values, containing the signal that must be loaded. The caller must ensure that enough data is allocated.
<i>Output:</i>	Returnvalue	E_NO_ERRORS E_NO_GENERATOR E_INVALID_VALUE

Remark: When generating a predefined signal, like e.g. a sinewave, the memory is filled with a sine wave pattern and the generator operates in DDS mode. So each time one selects signal type Arbitrary, the memory has to be filled again with the user defined pattern.

Set the generator output state

word SetFuncGenOutputOn(word wValue);

Description: This routine switches the output of the function generator on or off.

Input: wValue The new output state
 0 output is off
 1 output is on

Output: Returnvalue E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

Get the current generator output state

word GetFuncGenOutputOn(word *wValue);

Description: This routine determines the current setting of the function generator output

Input: -

Output: *wValue The current setting of the output
 0 output is off
 1 output is on

 Returnvalue E_NO_ERRORS
 E_NO_GENERATOR
 E_INVALID_VALUE

If you have any suggestions and/or remarks concerning the DLL's or the manual, please contact:

TiePie engineering
PO Box 290
8600 AG SNEEK

Visitors address:

TiePie engineering
Koperslagersstraat 37
8601 WL SNEEK
Tel.: +31 515 415 416
Fax: +31 515 418 819

